

The manual is divided into sections distinguished by two-digit numbers which correspond to the spare parts microfiches and repair tariff.

The **GENERAL INFORMATION and TECHNICAL DATA (00.)** section has the dual purpose of introducing the model and supporting the rest of the manual.
It includes technical data tables and specific information relating to the remaining sections of the manual.


The other sections (10. - 18. etc.) contain descriptions of repair operations.

NOTE *Section 10 describes the removal and refitting of the power unit.*

The engine bench overhaul procedure is published in a separate file identified by its own publication number. It should be inserted, in accordance with the engine size, in the appropriate sections of the "Petrol engine overhaul" or "Diesel engine overhaul" binders.

Graphic symbols are used in place of descriptions of mechanical components, operations or repair methods.

The shading of a component or part serves to highlight the part and to draw the reader's attention to the item to be measured or checked.



Small end diameter

Example:

Big end bearing location



Tighten to torque

**THIS MANUAL IS PUBLISHED IN LOOSE-LEAF FORMAT TO FACILITATE MODEL UPDATING.
THE "SERVICE INFORMATION" DETAILS SHOULD BE INSERTED IN THE VARIOUS SECTIONS
AS AND WHEN THEY ARE ISSUED.**


Introduction

The **FIAT 126 BIS** is a 3-door hatchback with monocoque body, rear-mounted engine and rear wheel drive.

The engine has 2 in-line horizontal cylinders with clockwise rotation; it is water cooled and longitudinally mounted in the rear compartment.

The **FIAT 126 BIS** is fitted with a 703 cm³ engine which runs on 4-star petrol and delivers a power (EEC) of 18.5 kW (26 hp).

Symbols

	Removal Disconnect		Operation
	Refitting Connect		Tolerance Weight imbalance
	Dismantling Disassembly		Preload
	Fitting Reassembly		Rotation
	Tighten to torque		Preload
	Tighten to torque plus angle		Angle Value of angle
	Stake nut		Compression ratio
	Setting Adjustment		Grading Categories
	Visual examination Check		Oversize ... greater Maximum
	Undersize ... smaller Minimum		
	Warning		Engine speed
	Lubricate Lightly lubricate		Ratio
	Replacement Genuine spare parts		Pressure
	Bleed braking system		Temperature
	Surface to be machined Machine finished		Temperature <0°C Cold Winter
	Interference Force fit		Temperature >0°C Hot Summer
	Dimension to be measured Measurement - Check Thickness - Clearance		Windscreen wiper with washer pump
	Inlet		Rear window wiper with washer pump
	Exhaust		Engine



P1V001A01


3/4 front view




P1V001A02

3/4 rear view with tailgate open


00.0



View of car with tailgate open



View of car with tailgate open, rear seat folded and
cutaway of front luggage compartment



1. Instrument panel - 2. Fan - 3. Rear fog lamp - 4. Rear window wash/wiper - 5. Windscreen demist/de-icer - 6. Air vent - 7. Air volume adjustment - 8. Loudspeaker housing - 9. Stowage compartment - 10. Stowage shelf - radio housing - 11. Heater/ventilation controls - 12. Bonnet release catch - 13. Windscreen wash/wiper - 14. Ignition switch - Parking lights - Steering lock - 15. Horn push - 16. Main/dipped beam headlamps - 17. Direction indicators - 18. Heated rear window - 19. Hazard warning lights - 20. Exterior lights

INSTRUMENT PANEL

Low water warning light

Hand brake and low brake fluid level warning light

Fuel reserve warning light

Free warning light

Parking lights warning light

Main beam headlamps warning light

Hazard lights warning light


Low battery charge warning light


Low oil pressure warning light

Direction indicators warning light

Rear fog lamp warning light

Heated rear window warning light






1. Air temperature adjustment lever
2. Air volume adjustment lever
3. Air to screen/vehicle selection lever
4. Central vent open/close lever
5. Two-speed fan switch


	CHASSIS	ENGINE	VERSION	3 DOORS	4-SPEED GEARBOX
 703	ZFA 126A 100	126 A02 000	126 AA 43A	•	•

Engine identification: stamped on cylinder block near petrol pump




A. Engine type
B. Engine serial number

A Vehicle type identification code and chassis number



P1V005A02

B V.I.N. Plate (E.E.C. standards)




- A. Manufacturer's name
- B. Approval number
- C. Vehicle type identification code
- D. Chassis serial number
- E. Maximum laden weight
- F. Maximum laden weight plus trailer
- G. Maximum permissible front axle load
- H. Maximum permissible rear axle load
- I. Engine type
- L. Body version code
- M. Number for spares
- N. Space reserved for diesel vehicles (correct smoke absorption coefficient)

General information

126 BIS

00.0

DIMENSIONS (mm)



Luggage carrying capacity (VDA procedure)

- Front compartment:
- Rear compartment: seat in normal position
 - seat half folded
 - seat fully folded

dm³ 55
dm³ 110
dm³ 270
dm³ 500


Height refers to unladen vehicle

P1V006A01

WEIGHTS (kg)

		620
	$+ 345 =$ 	965
		347
		618
Vehicle in running order		
		Not suitable for towing

 * 65 { 25 kg in front luggage compartment
40 kg in rear luggage compartment

POWER UNIT	
GEARBOX	
Speed km/h (2 persons + 20 kg)	      34 53 84.5 116 30
Gradient fully laden	      24 14 8 4.6 26.3
Fuel consumption as per ECE standards (litres/100 km)	  Urban cycle (A) 5.8 Constant speed of 90 km/h (B) 4.4 Constant speed of 120 km/h (C) — Average consumption (CCMC proposal) $\frac{A + B + C}{3}$ —

00.0

SEAT MATERIALS AND COLOURS	
Mixed (Cloth/Imit. leather) - 346	
Meteor Ivory	205
White	224
Oslo Grey	626
Aegean Blue	444
Racing Red	854


OPTIONAL FEATURES (Italian market only)

Inertia reel front seat belts	■
Hazard warning lights	■
Reclining front seats	▲
Rear seat belts	▲
Rear window wash/wiper + opening rear side windows	▲
Additional external rearview mirror	▲






■ standard

▲ on request

CUTAWAY VIEW OF THE CAR SHOWING LAYOUT OF THE MECHANICS



00.0


Fluid	Part to be filled			Quantity	
				dm ³	(kg)
 Petrol RON 98-100				21	-
 50%  +  				4.8	-
	Total capacity of cooling system				
VS+ Superstagionale (SAE 10 W) (SAE 20 W) (SAE 30) (SAE 40)	Total capacity				- -
VS+ Supermultigrado (SAE 10 W/30) (SAE 15 W/40)				2.25	2
	Service capacity (drain and refill)				
 a = TUTELA ZC 90 				a	1.10 1
 b = TUTELA GI/A 				b	- -
 TUTELA W 140/M DA	a 	b 	Limited slip	a	- -
 a e b = TUTELA GI/A	a 	c 	d 	a	- -
 c = TUTELA W 90/M-DA	b 			b	- -
 d = K 854				c	- -
 d = K 854				d	0.14 0.127
 TUTELA DOT 3	Total capacity				
				0.35	0.35
 +   ~ -10°C  ~ -20°C				2	-
				2	-

Olio Fiat Lubricant specifications

for cars and commercial vehicles

Product name	Description International designation	Application
VS ⁺ Superstagionale	SAE 40	Temperature 0°C - > 35°C
	SAE 30	Temperature 0°C - < 35°C
	SAE 20 W	Minimum temperature - 15°C - 0°C
VS ⁺ Supermultigrado	SAE 10 W/30	Temperature below -15°C - 30°C
	SAE 15 W/40	Temperature - 15°C - > 35°C
VS ⁺ Turbo Synthesis	SAE 15 W/40	Synthetic based detergent oil for petrol engines. API "SF" series. Better than European CCMC-G2 specification
		Temperature - 15°C - > 40°C
VS Diesel Superstagionale	SAE 40	Temperature 0°C - 50°C
	SAE 30	Temperature - 5°C - 30°C
	SAE 20 W	Temperature - 15°C - 15°C
VS Diesel Supermultigrado	SAE 10 W/30	Diesel engine oil. API "CD" series. To MIL-L-2104 D and CCMC-D2 specifications
	SAE 15 W/40	Diesel engine oil. API "CD" series. To MIL-L-2104 D and CCMC-PD1 specifications
VS Turbo D		Diesel engine oil. API "CD" series. To MIL-L-2104 D and CCMC-PD1 specifications
		Temperature - 15°C - > 40°C
TUTELA ZC 80S		SAE 80/W oil. To MIL-L-2105 and API GL4 specifications
TUTELA ZC 90		SAE 80 W/90 oil - non-hypoid EP - for manual gearboxes, containing anti-wear additives.
TUTELA W 90/M DA		Special SAE 80 W/90 EP oil for ordinary and limited slip differentials. To MIL-L-2105 C and API GL5 specifications
TUTELA GI/A		"DEXRON II" automatic transmission fluid.
TUTELA JOTA 1		Lithium-based grease, NLGI 1 consistency.
		Multi-purpose, except components particularly exposed to water which require specific greases
TUTELA MRM2		Water-repellent lithium-based molybdenum disulphide grease, NLGI 2 consistency
TUTELA MR3		Lithium-based grease, NLGI 3 consistency
TUTELA DOT 3 TUTELA DOT 4		Hydraulic brake fluid, to U.S. FMVSS no. 116, SAE J 1703, ISO 4925 and CUNA NC-956-01 standards
K 854		Lithium-based grease, NLGI 000 consistency, containing molybdenum disulphide
SP 349		Special castor oil and sodium based grease containing graphite and molybdenum disulphide, compatible with brake fluid and rubbers
Autofà DP1 Liquid		Alcohol-based liquid detergent
Paraflu Liquid ¹¹ FIAT		Monoethylene glycol based anti-freeze with inhibitors for cooling systems
		Cooling systems Concentration 35% down to - 25°C 50% down to - 35°C
Diesel Mix		Protective additive for diesel engines
		Mix with diesel (17 cc per 10 litres)

Diagram showing passenger compartment heating/ventilation system



1. Air intake pipe
2. Radiator bleed pipe
3. Passenger compartment heating radiator
4. Electric fan
5. Delivery fitting on cylinder head
6. Expansion tank
7. Radiator
8. Thermostat
9. Delivery pipe to passenger compartment heating radiator
10. Return pipe from passenger compartment heating radiator
11. Regulation controls
12. Cut-off valve control cable
13. Cut-off valve

50.

PASSENGER COMPARTMENT HEATING/VENTILATION SYSTEM

Description of system (refer to diagram on previous page)

Coolant from fitting (5) on the cylinder head reaches the passenger compartment heating radiator (3) located inside the heating-ventilation unit.

The coolant then returns to thermostat (8) through pipe (10).

A cut-off valve (13) located on delivery line (9) allows heating to be turned on or off by cutting off the flow of coolant to the passenger compartment heating radiator (3).

The heating and ventilation system consists of two units, one located in the front luggage compartment containing the passenger compartment heating radiator (3) and fan (4) - the other inside the passenger compartment including regulation controls (11), air flow adjustment and deviation flaps and cut-off valve (13) for turning the heating on and off.

Operation (refer to diagram below)


Lever (1) controls the cut-off valve to increase or decrease (to cut-off point) the flow of coolant to the passenger compartment heating radiator in order to regulate the temperature of the air supplied by the heating system.

Lever (2) moves the flap that adjusts the flow of air from the heating system.

Lever (3) moves the flap that directs the air flow towards the top (A) or bottom (C) outlets.


Lever (4) opens or closes central adjustable outlets (B).

Switch (5) activates the fan and adjusts the speed (and consequently the air flow) to two settings.



1. Air temperature adjustment lever	5. Fan activation switch
2. Air flow adjustment lever	A. Top windscreens outlets
3. Windscreens-footwell air distribution lever	B. Central outlets
4. Central outlet open-close lever	C. Lower outlets

REMOVING - REFITTING HEATER UNIT




P1V003H02




P1V003H01

- Undo the fastening studs and remove the heater unit shield.



P1V003H03


- Disconnect the passenger compartment radiator delivery and return lines and save the coolant.



P1V003H04

- Back off the heater unit retaining nuts.
- Disconnect air intake sleeve (1) from the wheel arch.
- Remove the heater unit.


50.




DISMANTLING HEATER UNIT




- Disconnect the bleed pipe from the passenger compartment heating radiator (1).
- Back off the bolts retaining the passenger compartment radiator and remove from the heater unit.




- Remove the connecting bolts from round the outside of the two halves and separate.




Heater unit case and passenger compartment heater radiator.

REMOVING-REFITTING
AND DISMANTLING
ELECTRIC FAN UNITRemoving-refitting
electric fan unit


- Back off retaining screws (2);
- disconnect connector (2).



P1V005H01



P1V005H02




P1V005H03



Removing-fitting electric fan from screw

- Back off the screws indicated.





P1V005H04

Dismantling-fitting fan from power unit

- Release the retaining clip and withdraw the impeller.


50.




DISMANTLING HEATING SYSTEM CONTROL UNIT

Removing-refitting control lever and cable unit.


Remove fasteners indicated by arrows in the diagram.



NOTE Operations for removing/refitting control unit from car are described in Section 70 Bodywork.




View of control unit




Separating halves of case


Release connection clips around the outside.



P1V007H01



P1V007H02




P1V007H03

Top case half and warm and cold air blender flap.

Dismantling-fitting bottom air flow deviation flap.

Bottom flap and air flow deviation flap.

50.




REMOVING - REFITTING COOLANT CUT-OFF VALVE





- Disconnect control cable from cut-off valve.
- Back off screws fastening valve to heater control case indicated by arrows.



- Drain the system, then slacken the clips round the inlet and outlet pipes.
- Refit the valve by carrying out removal operations in reverse order.
- Top up coolant in cooling system.





View of coolant cut-off valve

FRONT LUGGAGE COMPARTMENT LID

P1V01AM01


Removing-refitting front luggage compartment lid

- Back off the three bolts retaining the open limit device.



P1V01AM02


- Back off the four bolts retaining the hinge to the front crossbeam and remove the front luggage compartment cover.



P1V01AM03


Front luggage compartment lid separated from car

- Refit the front luggage compartment lid to the car by carrying out removal operations in reverse order.




P1V02AM01

Removing-refitting luggage compartment catch



P1V02AM02

- Remove the luggage compartment catch cover.



P1V02AM03




- Disconnect the cable from the catch as indicated, unscrew the two arrowed screws and remove.
- Carry out removal instructions in reverse order to refit, adjust the device position.

Adjusting luggage compartment lid catch


NOTE *The arrows indicate possible movements of catch.*

- Tighten retaining screws following adjustment.

REMOVING - REFITTING TAIL-GATE



P1V03AM01



P1V03AM02


Proceed as follows:

- Disconnect battery negative lead.
- Disconnect rear wiper motor connector.
- Disconnect rear screen connector.



P1V03AM03

- Withdraw cable bundle from tail-gate frame as shown in the diagram.



P1V03AM04

- Remove the safety clip fastening the damper to the tail-gate.


70.



P1V04AM01



- Remove the retaining ring and withdraw pins from hinges. Remove the tailgate from the car.
- Refit the tail-gate to the car by carrying out removal instructions in reverse order. Take care to insert the heated rear screen lead inside the frame first.



P1V04AM02




Removing-refitting hinge half from tail-gate

- Unscrew the bolts fixing the hinge half to the tail-gate.




P1V04AM03




Removing-refitting hinge half from body shell


- Unscrew bolt fixing hinge half to body shell.



P1V05AM01

**1,5 daNm**


P1V05AM02




P1V05AM03

Tail-gate separated from car

00.0




View of car with tailgate open



View of car with tailgate open, rear seat folded and
cutaway of front luggage compartment

70.




P1V06AM01

P1V06AM02




DISMANTLING - FITTING DEVICES FITTED TO TAIL-GATE





P1V06AM03

Removing-refitting rear wiper motor

- Disconnect battery negative lead.
- Disconnect rear wiper connector (see page 3)
- Remove the wiper blade as shown in the diagram.




P1V06AM04



P1V06AM05

- Unscrew the rear wiper blade operating pin retaining nut.
- Unscrew the rear wiper motor retaining screws and remove unit from tail-gate.
- Refit the rear wiper motor by carrying out removal operations in reverse order.




P1V06AM06

P1V06AM07




Removing-refitting tail-gate buffer pads.

NOTE *Adjust pad position when refitting.*




P1V07AM01




Removing-refitting tail-gate catch

- Check weather strip condition: replace if damaged.




P1V07AM01

P1V07AM03



P1V07AM04

0,44 daNm



P1V07AM05

- Following adjustment, tighten retaining screws to specified torque

70.




P1V08AM01




REMOVING-REFITTING DOOR ASSEMBLY


- Disconnect the opening limit device as shown in the diagram.



P1V08AM02



- Unscrew the four bolts fastening the hinge to the body shell and remove the door assembly.




P1V08AM03




1,5 daNm

- Refit the door by carrying out removal operations in reverse order. Tighten bolts fixing hinges to body shell to the specified torque.



DISMANTLING – FITTING DEVICES FITTED TO DOOR




P1V09AM01




P1V09AM02



P1V09AM03



P1V09AM04



P1V09AM05

Door panel separated from car

70.




P1V10AM01



P1V10AM02



- Unscrew link fastening bolt and disconnect from door catch.
- Withdraw door closure safety rod and remove, operating from inside door frame.



P1V10AM03




P1V10AM04

- Unscrew the two glass guide channel retaining screws indicated in the box.
- Unscrew the three door catch retaining screws.




P1V10AM05



P1V10AM06


- Push the door catch inside the door, then release the connecting link to the outer handle and remove the door catch.



- Unscrew the two screws fixing the outer handle.

NOTE Remove the plug shown in the diagram to reach one of the two screws.

- Remove the outer door handle as shown in the box.




P1V11AM02


P1V11AM03




- Unscrew the retaining screw and withdraw the front glass guide channel.



P1V11AM04




- Unscrew the two screws fixing the glass link.





P1V11AM06

70.




P1V12AM01





P1V12AM02

- Loosen the bottom nut fixing the mechanical window device. Unscrew the three nuts indicated by arrows and remove the manual window device.




P1V12AM03





P1V12AM04

- Withdraw the glass from the bottom of the door.
- Extract the rear glass guide channel.






P1V12AM05

Rear glass guide channel separated from car




- Prie off the seal cover plate as shown in the box.
- Remove the inner window frame.

**Window glass outer and inner frames**

- Unscrew the two retaining screws and remove the deflector.


70.





P1V14AM01



- Remove the retaining pin using a drift and remove the deflector closure rod.




P1V14AM02



P1V14AM03

- Remove the two fixing rivets and loosen the arrowed screw.
- Remove the glass end stop pin as shown in the top box.
- Remove the deflector pin, as shown in the bottom box.



P1V14AM04



- Remove the deflector pin using special rivet pliers.




P1V15AM02

P1V15AM01



- Remove the door open limit device.
- Unscrew the four bolts fastening the hinges to the body shell.
- Remove the door.

Door frame assembly



P1V15AM03

Adjusting door catch striker



P1V15AM04

P1V15AM05

- Following adjustment, tighten the striker retaining screws.
- Remount and refit the door by carrying out removal operations in reverse order. Tighten hinge retaining screws to the specified torque.

1,8 daNm

70.



P1V16AM01




FRONT BUMPERS

Removing-refitting

- Disconnect the battery terminals and remove.




P1V16AM02



P1V16AM03

- Unscrew the two screws fastening the bumpers to the body shell and remove.



P1V16AM04




- Refit the bumpers by carrying out removal instructions in reverse order.





Position the bumpers on the guides located at the sides.

REAR BUMPERS





P1V17AM01



P1V17AM03

- Unscrew the two internal screws fastening the brackets to the body shell.
- Remove the bumpers together with the reversing, rear fog and number plate lights.



P1V17AM04

P1V17AM05




Position the bumper on the guides located at the sides.


70.




PROTECTIVE REAR MOULDING (located under rear bumper)




P1V18AM03



P1V18AM02



DOOR SIDE RUBBING STRIPS



P1V18AM05



Removing-refitting

- Remove the door trim panel (see page 9).
- Unscrew the central retaining screw and undo the two studs arrowed in the top box.
- Disconnect the rubbing strips.

NOTE *To remove easily, slide the strips toward the back of the car to release from the retaining clips.*

- Refit the strips by carrying out removal operations in reverse order.



SIDE RUBBING STRIPS IN BODY SHELL



P1V18AM07

Removing-refitting


- Remove the tapered peg from the fastening studs using a punch.
- Slide the strip toward the back of the car and remove.
- Carry out the same procedure for the front strip.
- Refit the strips by carrying out removal instructions in reverse order.

SIDE GRILLES

P1V19AM01

Removing-refitting


- Unscrew the four retaining screws and remove the side grille.
- Refit the grille by carrying out removal instructions in reverse order.



P1V19AM02

DOOR MIRROR

P1V19AM03

Removing-refitting

P1V19AM04


Door mirror assembly



P1V20AM02




STEERING WHEEL AND LOCK RELEASE




P1V20AM03

Removing-refitting


- Remove the horn cover as shown in the box.
- Unscrew the nut fastening the steering wheel to the steering column.
- Remove the steering wheel.



P1V20AM04



P1V20AM06



P1V20AM07

- Disconnect the three connectors located in the front luggage compartment and then pull off the steering lock release unit.


INSTRUMENT PANEL




P1V21AM01



P1V21AM02




P1V21AM04



P1V21AM03

- Remove the wheel as shown on the previous page.
- Unscrew the two screws shown in the diagram.
- Disconnect the connectors indicated and remove the instrument panel frame complete with switches.
- Unscrew the two instrument panel retaining screws, then take the two arrowed cable bundles out of the panel.
- Disconnect the connectors from the back of the instrument panel and remove from the facia.
- Refit the instrument panel by carrying out removal instructions in reverse order.


70.



P1V22AM01


P1V22AM02

CENTRAL CONSOLE



Removing-refitting.

- Remove the heating and ventilation lever knobs as shown in the box.
- Unscrew the nut and the three screws indicated by the arrows.
- Remove the glove compartment with speaker compartment, central console and radio compartment.



P1V22AM03

Glove compartment, central console and radio compartment.




P1V22AM04

HEATER CONTROL UNIT




Removing-refitting.

- Remove the glove compartment and central console as described in the previous paragraph.
- Disconnect the link by loosening the retaining screw as shown in the diagram
- Unscrew the two screws and nuts indicated by the arrows.
- Remove the heater control block from the car.




P1V23AM01


Heater control unit



P1V23AM02



P1V23AM04



P1V23AM03

- Loosen the three control links at the points indicated by the arrows.
- Unscrew the four arrowed screws and remove the control lever unit.
- Refit the control lever unit and heater control block by reversing the removal procedure.

70.



P1V24AM01



CENTRAL TUNNEL COVER

Removing-refitting.


- Unscrew the two retaining screws shown in the diagram and remove the rear cover.



P1V24AM02



- Unscrew the two screws shown in the diagram and remove the front glove compartment.





P1V24AM03

Tunnel cover

- Refit the tunnel cover by reversing the removal procedure.


HAT RACK AND REAR SQUAB RELEASE





P1V25AM02

Removing-refitting

- Disconnect the tail-gate support link rings.
- Disengage the hat rack from the pins and withdraw.




P1V25AM01




P1V25AM04

- Unscrew the two screws indicated and remove the hat rack support trim.




P1V25AM03




P1V25AM06

- Unscrew the two screws indicated and remove the rear squab release.
- Refit the hat rack by reversing the removal procedure.




P1V25AM05

70.



PASSENGER GRAB HANDLE



P1V26AM01



P1V26AM02

Removing-refitting

- Prise off the cover plate and unscrew the two retaining screws. Remove the passenger grab handle.




ROOF PANEL

P1V26AM03

Removing-refitting

- Remove the sun visors by unscrewing the four retaining screws indicated.



P1V26AM04

P1V26AM05

- Unscrew the three rear threaded plugs shown in the diagram using a suitable wrench as shown in the box.
- Detach and remove the roof panel, working through the tail-gate opening.
- Refit by reversing the removal procedure.

FRONT SEAT


P1V27AM01

Removing-refitting

- Push the seat fully forward and release from guide rail.




P1V27AM02

Front seat assembly.

P1V27AM03

- Remove the seat cover and padding.

70.



P1V28AM01

Removing-refitting guides

- Remove the four guide rail retaining rivets as shown in the diagram.
- Remount and refit the front seat by reversing removal and disassembly procedure.




REAR SEAT

P1V28AM02

Removing-refitting

- Lift the back seat cushion by releasing from stops and withdraw.



P1V28AM03

Back seat cushion

- Release the rear squab by means of the release lever.




P1V29AM01

- Unscrew the two retaining screws, then remove the squab.



P1V29AM02

- Refit the rear squab and cushion by reversing the removal procedure.




P1V29AM03


70.



P1V30AM01



FRONT LIGHT CLUSTERS




P1V30AM02



Removing-refitting

- Remove the rear trim.



P1V30AM03




- Disconnect the two connectors shown in the diagram.
- Push from inside the car to remove the light cluster from its housing and release from the retaining pins.
- Refit the light cluster to the car by reversing the removal procedure.

NOTE *Each time a front light cluster is removed and refitted, check headlamp alignment and adjust by means of the adjustment screw (see instructions in car owner handbook).*

FRONT TURN SIGNALS




P1V31AM01



P1V31AM02

- Back off the two retaining screws.
- Remove the turn signal from its housing and disconnect the connectors shown.
- Remove the turn signal.



P1V31AM03

- Refit the turn signal by reversing the removal procedure.



P1V32AM01

TAIL-LIGHT CLUSTERS




Removing-refitting

- Unscrew the retaining screws and remove the lens.




P1V32AM02




P1V32AM03

- Disconnect the connector and remove the light cluster from the car.
- Refit the light cluster by reversing the removal procedure.




P1V32AM04

REAR NUMBER PLATE LIGHT



P1V32AM06



P1V32AM05



Removing-refitting

- Prise out the number plate light bulb as indicated in the top box. Disconnect the connector and withdraw the cables.
- Refit the number plate light by reversing the removal procedure.


REVERSING AND REAR FOG LIGHTS



P1V33AM03



P1V33AM01



P1V33AM02

COURTESY LIGHT




P1V33AM04



P1V33AM05

- Remove the courtesy light lens.
- Unscrew the two screws shown in the diagram and disconnect the connector.
- Refit the courtesy light by reversing the removal procedure.

70.



P1V34AM01



SWIVEL-OPENING SIDE WINDOWS




P1V34AM02



Removing-refitting

- Unscrew the three fastener block retaining screws.




P1V34AM03 P1V34AM04





- Open the side window until the pins come out of the hinges on the body.


- Remove the rivets fixing the fastener to the glass, then unscrew the lock collar and withdraw the pin.





P1V35AM02



P1V35AM01




P1V35AM05



P1V35AM03

P1V35AM04


- Extract the screw fixing the hinge to the glass and remove.
- Remove the frame lining.



P1V35AM06


- Refit the fastener by tightening the rivet with a pair of pliers.
- Finish remounting and refit the side window by reversing the procedure.

18.



Components of the release bearing, release fork and fork pivot shaft

1. Clutch cable
2. Clutch release lever complete with fork pivot shaft
3. Bush
4. Clutch release fork
5. Release bearing
6. Release bearing spring clips
7. Release bearing sleeve




CLUTCH RELEASE BEARING


Removing/refitting clutch release bearing clips

The arrows indicate the spring clips

Components of the clutch release mechanism supplied as spares


1. Clutch release lever
2. Clutch cable
3. Clutch pedal
4. Pedal return spring






Removing/refitting clutch assembly

NOTE *To remove the clutch, it is necessary to remove the gearbox/differential unit.*
See section 21-27. for removal of the gearbox/differential unit.



Using centring pin 1870085000 to align the driven plate during clutch reassembly.

DRIVEN PLATE - CLUTCH COVER




P1V007J07

Checking

NOTE *If the friction linings on the driven plate are excessively worn, either they or the complete driven plate should be renewed.*
If the clutch cover shows signs of wear, overheating or deep scoring, the cover assembly should be renewed.

CLUTCH PEDAL**Adjusting clutch pedal position**

Adjust the nut (2) and locknut (1) of the cable until the clutch pedal is approximately 20 mm below the level of the brake pedal.



18.A

1870085000 Driven plate centring pin

Torque wrench settings








PART	Thread	Torque wrench setting
		daNm

Clutch cover to flywheel bolt	M 6	1
Nut for securing complete lever on clutch release pivot fork	M 8	1.5
Clutch release fork bolt	M 8	2.5
Clutch release sleeve support bolt	M 6	0.83

21-27.

Raise the car and disconnect the parts illustrated below:

- disconnect the heater duct guard;
- disconnect the flywheel guard;
- unscrew the bolts securing the starter motor to the gearbox and rest the starter motor in the engine compartment;



- disconnect the speedometer cable (1);
- disconnect the reversing light switch wire (2);

- disconnect the gear control rod from the gearshift lever;



- remove the gearbox support crossmember from the body;

SEQUENCE OF OPERATIONS


Position the car on ramps.

Proceed as follows:


- disconnect the battery earth lead (under the bonnet);
- open the tailgate, remove the interior trim and fold down the rear seat squab;
- disconnect the following:
- disconnect the clutch cable (shown by the arrow);




- remove the flywheel guard top bolt;



- fit the crossbar 1870414000 and support the engine on the special hook (as shown in photo opposite);




– disconnect the left driveshaft;



– disconnect the right driveshaft;



– lower the engine slightly to facilitate withdrawal of the gearbox;



– unscrew the bolts securing the gearbox-differential unit to the engine;
 – manoeuvre the gearbox-differential unit to release it from the locating pins on the engine, and slide the input shaft out of the driven plate;
 – lower the hydraulic jack and withdraw the gearbox-differential unit


NOTE *To refit the gearbox-differential unit, simply reverse the order of procedure for removal.*



Clutch pedal height.


21-27.

LONGITUDINAL SECTION




SEQUENCE OF OPERATIONS


- Drain the gearbox oil;
- place the gearbox on rotating stand 1871000000 using bracket 1871001007;




Differential unit complete with driveshafts




Bellhousing



1871001007




P1V005B03




P1V005B05


Clutch release bearing



Release bearing retaining clips



P1V005B06



Locking pin

Spring clip

Input shaft


Gearbox and differential

Dismantling at the bench




126 BIS

21-27.


Rear cover




Top cover




Reversing light
switch




Detent balls and springs
cover bolts





Speedometer drive-
gear



Dismantling reverse gear selector fork and rod





Withdraw the cotter pins from the mainshaft and counter-shaft lock nuts




Removing mainshaft and countershaft nuts



To slacken the mainshaft and countershaft nuts, engage two gears simultaneously to stop the shafts rotating.






Dismantling 3rd-4th gear selector rod





21-27.




Dismantling 3rd-4th gear selector fork, 1st gear selector fork, 1st-2nd gear selector rod complete with 2nd gear fork, speedometer drivegear, 2nd speed hub, synchro sleeve and gear




Dismantling reverse idler shaft and gear




Dismantling mainshaft with front and rear bearings



Dismantling countershaft - bevelled pinion and gear train




P1V009B02



P1V009B03

Dismantling retaining plate and rear bearing




P1V009B04



Gearbox casing

The gearbox must not be cracked, and the bearing and rod housings must not be worn or damaged. Contact surfaces must be flat (minor imperfections may be remedied using a fine file).

Oil breather




P1V009B05




Ensure that the oil breather is not blocked.

21-27.



P1V010B01




P1V010B02



Dismantling/refitting
release bearing fork and
shaft

The bushes (indicated by
the arrows) should be
renewed if there is ex-
cessive play in the fork
shaft.




P1V010B03




Dismantling bush from release bearing
sleeve

NOTE Use an ordinary drift to fit the bush.




P1V010B04



P1V010B05




Dismantling release bearing sleeve



P1V011B01

Release bearing sleeve

1. Bush
2. Oil seal
3. O-ring seal



P1V011B02

P1V011B03

Fitting oil seal onto release bearing sleeve

The oil seal and O-ring must always be replaced new.


NOTE After the gearbox has been dismantled, the various components must be checked carefully. The following sections contain instructions for the main checks and measurements necessary in order to decide whether a part is suitable for reuse. The correct refitting procedures are also described, and special tools are indicated to facilitate gearbox reassembly.

Checking bellhousing, gearbox casing and rear cover

The gearbox casing and bellhousing must not be cracked, and the bearing and rod housings must not be worn or damaged. The contact surfaces must be flat (minor imperfections may be remedied using a fine file).

Gearbox train

21-27.



P1V012B01

COUNTERSHAFT ASSEMBLY

Gears - Bushes


The teeth of gears and synchronizer rings must not be excessively chipped or worn.

Also check that the bush surfaces and gear inner surfaces do not show signs of seizure or abnormal wear (the maximum clearance must not exceed 0.20 mm).


Bearings

The bearings should be renewed if they show signs of scoring, overheating or excess wear.


Countershaft - pinion complete with gears, hubs, bearings, synchro rings and sleeves




SYNCHRONIZERS

2nd gear hub,
synchro ring and
sleeve assembly


P1V013B01

3rd-4th gear hub,
synchronizer and
sleeve assembly

P1V013B03



P1V013B02



P1V013B04

Synchro hubs - Sleeves

Check that the hubs and sleeves are not chipped and that they slide freely with neither tight spots nor excessive play.

The sleeve splines must not be worn, or replacement will be necessary.


Synchronizers

The inner surfaces of the synchronizer rings must not show signs of wear or out of round. It is good practice always to renew the synchro rings.

MAINSHAFT

Check that the gear teeth are not chipped or excessively worn.

If the mainshaft needs to be replaced, it is good practice also to replace all the countershaft gears.




P1V013B05

Gearbox train

21-27.

REVERSE IDLER SHAFT AND GEAR


Check that the gear teeth are not excessively chipped or worn. Also check that the shaft and inner bush do not show signs of seizure or abnormal wear.



INPUT SHAFT

Check that the sleeve and shaft splines are not worn or damaged.


SELECTOR RODS AND FORKS



Checking selector rods and forks

The forks must not show signs of distortion or wear on the surfaces in contact with the synchro sleeves. The rods must not show signs of distortion or wear on the detent ball housings. They should slide freely in their housings without excessive play.


DRIVESHAFT, STUB AXLE AND REAR WHEEL HUB ASSEMBLIES



Gasket set for gearbox/differential overhaul



The gaskets must be replaced whenever parts are dismantled









DIFFERENTIAL ASSEMBLY

COAT



A





Differential complete with driveshafts



To dismantle the sleeve joining the drive shaft to the stub axle coupling, remove the spring clip (indicated by the arrow).

Dismantling pinion gear shaft retaining collar

Dismantling crown wheel from differential casing



If the crown wheel needs to be replaced, it is good practice also to renew the pinion.

21-27.




Dismantling and disassembling differential half casings and pinion gear shaft

The pinion gear shaft must not show signs of seizure, wear or excessive play between it and the carrier. The working surfaces of the differential pinion and side gears must not be chipped or worn.






Dismantling side gear half shaft, adjustment shim and bipod joint

1. Driveshaft
2. Side gear
3. Adjustment shim
4. Joint pad




Checking driveshaft

Check that the driveshaft is not distorted or out of true, and that the surface in contact with the oil seal is not worn. If the bipod joint is defective, replace the driveshaft.



Removing and refitting differential carrier roller bearings



The bearings should be replaced if they show signs of scoring, overheating or excessive wear.



Assembly of side and pinion gears and clearance adjustment



Replacement side gear adjustment shims are supplied in the following thicknesses: 0.70 - 0.80 - 0.90 - 1.00 - 1.10 - 1.20 - 1.30 mm



NOTE Use the appropriate adjustment shim to obtain the correct clearance between side and pinion gear.

The clearance is correct when the assembly rotates without play and with slight resistance.

21-27.




F / I / A / T



Fitting side gear adjustment shim

NOTA Adjustment shims of the same thickness must be assembled on the side gears.




Fitting differential half casings

Ensure that the reference marks on the half casings (indicated by the arrows) coincide.




Lubricate the parts with gearbox oil before final assembly.



4,5 daNm


Tightening the crown wheel and differential half casings to the correct torque




Fitting driveshaft gaiter bush




Grease tool 1870103000 to facilitate assembly of the bush in the gaiter.



Cross-section of the gearbox/differential assembly on the driveshafts




21-27.




CALCULATING THICKNESS "T" OF PINION ADJUSTMENT SHIM

$$T = 0.90 + a - (\pm \frac{b}{100}) - c$$




Fitting rear bearing and plate



Positioning dummy pinion on gearbox casing


Resetting dial indicator on a reference sur- face

A preload of 1 mm should be set because "a" can sometimes be a negative value.



Measuring "a"


"a" = Average value of dial indicator readings taken on the supports






Measuring "b"

"b" = Value engraved on pinion shank

The arrow indicates the area where "b" is engraved. The number indicating "b" (in hundredths of a mm) is preceded by a plus (+) or minus (-) sign.



Resetting the dial indicator on dummy shaft 1870037000



Components of the "c" train

3rd gear bush

3rd-4th gear hub

4th gear bush

Pinion bearing inner race

Measuring "c"

"c" = Difference between height readings of geartrain and dummy shaft.

NOTE *The geartrain height must always be greater than the dummy shaft height; if not, the bushes must be renewed.*



Replacement pinion adjustment shims are supplied in the following thicknesses: 0.10 - 0.15 mm.

NOTE *After calculating the correct thickness "T" of the adjustment shims, use the appropriate replacement shims to obtain a thickness as close as possible to that calculated.*

Example

If "b" engraved on the pinion shank is a positive value:

0.90 = fixed value

$$S = 0.90 + a - \left(\pm \frac{b}{100} \right) - c$$

$$T = 0.90 + a - \left(+ \frac{b}{100} \right) - c = 0.90 + a - \left(\frac{b}{100} \right) - c$$


If "b" engraved on the pinion shank is negative:

$$T = 0.90 + a - \left(- \frac{b}{100} \right) - c = 0.90 + a + \left(\frac{b}{100} \right) - c$$


4th gear

3rd-4th gear selector rod groove,
facing 3rd gear1st gear selector fork groove, facing
4th gear


3rd gear

Preparing countershaft gear-
train and positioning in gearbox
casing

P1V025B01




P1V025B02




P1V025B03

Adjustment shim


Fitting countershaft (pinion) in gearbox
casing and other components

P1V025B04





P1V025B06

Fitting reverse idler shaft and reverse gear




P1V025B05



21-27.



Fitting rear bearing, 2nd gear bush and hub and speedometer drivegear




Fitting tool 1870343000 (for locking pinion while measuring pinion-to-crownwheel backlash) and tightening countershaft retaining nut to the correct torque



Fitting differential unit complete with driveshafts




*Smear **Ermetico Optimus 854365** on the surface between gearbox casing and bellhousing.*



P1V027B01

Fitting bellhousing to engine

3,4 daNm




P1V027B02


Tightening bellhousing gearbox bolts to the correct torque



The bellhousing/gearbox bolts should be tightened to the correct torque after the bearing housings have been fitted.



P1V027B03



P1V027B04


Fitting bearing housings and preload shims

NOTE *Smear the bearing housing and gearbox casing surfaces with **Ermetico Optimus 854365**.*




The preload shims must be left unrestrained to allow free bearing movement.

21-27.






Tightening differential preload shims (to allow the bearings to bed in)

Use tool 1855147000 to tighten the shims until resistance is felt (starting from shim on crownwheel side).



Bedding in differential bearings


Slacken the locking bolt on tool 1870343000 and rotate the countershaft by several revolutions to allow the differential bearings to bed in.




Checking pinion to crownwheel backlash

The backlash must be 0.08 - 0.13 mm, and is best checked on at least four points of the crownwheel.

Before each individual measurement of the pinion to crownwheel backlash, ensure that the pinion is locked by the bolt on tool 1870343000




Adjusting pinion-to-crownwheel backlash




Checking differential carrier
roller bearing preload

The preload must be 128 - 147 Ncm (13 - 15 kgcm).


If it is incorrect, turn the pre-load shims by the same amount so as not to alter the pinion-to-crownwheel backlash.




21-27.




Dismantling 2nd gear train, speedometer drivegear and tool 1870343000




Fitting 1st gear and 3rd-4th gear selector forks




Fitting mainshaft and front bearing



P1V031B01




P1V031B02




P1V031B03



Fitting input shaft with locking pin and spring clip



P1V031B05




P1V031B04

Fitting mainshaft bearing,
rear side






Fit the bearing with
the flat edge (indicated
by the arrow)
facing the retaining
plate (1).






P1V031B06

Fitting 2nd speed gears with bush and
synchronizer



21-27.




 Fitting 1st-2nd gear selector rod with 2nd gear synchro sleeve, hub, sliding keys and plate.
Tightening 1st gear selector fork and fitting pawl



 Fitting 3rd-4th gear selector rod. Tightening 3rd-4th gear selector fork and fitting pawl





 Fitting and tightening reverse selector rod and fork



Fitting detent balls and springs



Lightly lubricate the seal before final assembly





4,9 daNm



Fitting speedometer drivegear and tightening mainshaft and countershaft locking nuts




To stop the shafts rotating, engage two gears simultaneously (4th gear and reverse). If at the specified torque the notch on the nut does not line up with the hole on the shaft, continue tightening until the cotter pin can be inserted.



Fitting rear cover with gear engagement lever




Ensure that the gear engagement lever is inserted in the selector rod strikers.




Lightly lubricate the seal before final assembly.


21-27.




Fitting reversing light switch



Fitting speedometer drive housing




Fitting top cover




Fitting clutch release bearing sleeve

P1V035B01



**Fitting release bearing and retaining clips
(indicated by the arrows)**


P1V035B02




Fitting preload shim retaining plates

P1V035B03

21-27.




Fitting gaiter



Fitting sleeves joining driveshafts to wheel
couplings and retaining clip (indicated by
the arrow)

GEARSHIFT LINKAGES



21-27.A


1840005000	Universal extractor	1870414000	Crossbar for supporting engine during removal/refitting of gearbox/differential
1840206000	Impact extractor (to be used with specific accessories)	1870438000	Part for extracting differential carrier inner bearing races (use with 184005001, 184005312 and 1840054000)
1840207813	Accessory (Ø 14-18 mm) for extracting bellhousing sleeve bush (to be used with 1840206000)	1870600000	Bracket for supporting gearbox-/differential during removal and refitting
1850113000	Gearbox drain plug spanner (12 mm)	1871001007	Bracket for supporting gearbox-/differential unit during overhaul (mount on 1861000000 or 1871000000)
1855083000	Gearbox oil level plug spanner (13 mm)	1895697000	Dynanometer (0-4.90 Nm scale) for measuring bearing preload
1855147000	Adjustment spanner for differential carrier bearing preload shims	1895708000	Tool for measuring pinion-to-crownwheel backlash (use with 1895882000)
1870037000	Reference shaft for measuring total length of pinion gears and bearings (use with 1895684000)	1895882000	Dial indicator (0.001 mm graduations) for use with special tools (measurement capacity 10 mm, shank length 88 mm)
1870342000	Tool for fitting oil seal on gearbox front cover	1895883000	Dial indicator (0.001 mm graduations) for use with special tools (measurement capacity 10 mm, shank length 60 mm)
1870343000	Tool for locking 2nd synchro sleeve during measurement of pinion-to-crownwheel backlash		
1870356000	Accessory for checking differential bearing preload (use with 1895697000 and 1855147000)		
1870380000	Tool for calculating pinion adjustment shim thicknesses (use with 1870404000)		
1870404000	Dial indicator bracket, for depth or projection measurements (use with 1895883000 and 1870380000)		

PART	Thread	Torque wrench
		settings daNm

Starter motor bolt	M 8	2.5
Clutch cable reaction bracket nut	M 8	1.5
Nut for bellhousing stud	M 8	2.5
Bellhousing bolt	M 8	2.5
Gearbox casing/bellhousing bolt	M 10 x 1.25	3.4
Gearbox countershaft with nut and cotter pin	M 14 x 1.5	4.9 (*)
Mainshaft nut and cotter pin	M 14 x 1	4.9 (*)
Reverse idler shaft bolt	M 8	1.5
Selector fork bolt	M 5	0.83
Gearshift lever bracket bolt	M 8	1.5
Self-locking nut securing inner collar to gearshift lever	M 8	1.6
Self-locking nut securing inner collar to gearshift lever	M 8	2
Self-locking nut for gear selector linkage bolt	M 6	1
Bolt securing crownwheel to differential carrier	M 8	4.5
Nut for differential bearing housing stud	M 8	1.5
Nut to be staked, securing coupling to rear wheel stub axle	M 18 x 1.5	
Bolt securing sleeve to stub axle coupling	M 8	2.5
Bolt securing bearing retaining plate	M 8	2.2

(*) If at the specified torque the notch on the nut does not line up with the hole on the shaft, continue tightening until the cotter pin can be inserted (angle less than 60°)


BRAKE PEDAL



P1V001D04

Removing-refitting brake pedal

In order to remove the brake pedal, the nut shown by the arrow has to be undone before removing the brake pedal return spring, the clutch cable and the pedal.



P1V001D01




the parts concerned with grease before fitting.


BRAKE FLUID RESERVOIR

Checking insufficient brake fluid level warning device

NOTE *Periodically check the operation of the warning device by pressing on the top of the reservoir cover (as shown by the arrow); with the ignition switch in the ON position the brake fluid warning light should come on.*



P1V001D02



P1V001D03

Removing-refitting reservoir and pipes connected to master cylinder





Before removing the reservoir, drain the brake fluid.




Bleeding hydraulic system.

33.




MASTER CYLINDER





Removing-refitting pipes connecting brake fluid reservoir to master cylinder

The arrows show the pipes to be removed.



Removing-refitting brake pipes from master cylinder




Removing-refitting master cylinder



Bleed braking system.

The arrows show the nuts fixing the master cylinder to the bodyshell.




P1V003D01

Removing-refitting master cylinder

When overhauling, always replace the seals; if there are any traces of abrasion or seizing in the master cylinder casing, replace the assembly.

Cross section of hydraulic braking system (master cylinder)





P1V003D02

1. Rear wheel brake fluid supply pipe union seat
2. Seat for pipe union supplying brake fluid from reservoir to rear brake circuit
3. Seats for pipe unions supplying brake fluid to front wheels
4. Seat for pipe union supplying brake fluid from reservoir to front brake circuit
5. Hydraulic pump casing complete with plug


33.

Hydraulic braking system components available as spares




NOTE Each time the pipes have to be removed check that they are not blocked by blowing through with an air jet. In the case of dents, kinks, cracks or loose unions, the pipes have to be replaced.

REMOVING-REFITTING




Removing front wheel hub cover



Removing front wheel hub retaining nut





Before removing the front wheel hub retaining nut, the staking have to be removed from the nut.





Fitting tool 1872257000 for retaining wheel cylinder piston whilst removing and refitting the shoes


33.




Removing-refitting brake shoe upper return spring



Removing-refitting brake shoe lower return spring




Removing-refitting brake shoe retaining pin



P1V007D01

Removing-refitting brake shoes

SHOES



P1V007D02



Checking shoes

The minimum permissible thickness for brake shoes is 1.5 mm.


Removing-refitting brake shoe clearance self-adjusting device

Check that self-adjusting device spring and washers are not worn or broken.

It is advisable to replace the self-adjusting device circlip.




P1V007D04



P1V007D05

33.



P1V008D01


BRAKE DRUMS



Checking and measuring brake drums

If the brake drums show signs of deep grooves or if they are unevenly worn, they must be skimmed.

The maximum permissible diameter oversize for brake drums is 0.8 mm.




P1V008D02



Longitudinal section of front brake drum

1. Wheel cylinder
2. Brake shoe upper return spring
3. Brake shoe retaining pin
4. Brake shoe lower return spring
5. Brake shoe support plate
6. Drum
7. Self-adjusting device
8. Brake shoe




P1V008D03




Cross section of front brake drum and self-adjusting device

1. Brake shoe retaining pin
2. Self-adjusting device
3. Brake shoes
4. Brake drum

WHEEL CYLINDER



Removing-refitting bolts fixing wheel cylinder to brake back plate



Removing-refitting brake fluid pipe from wheel cylinder





Bleeding hydraulic system

Removing-refitting and checking wheel cylinder components


When overhauling, always replace the seals and protective boots; if there are any anomalies in the cylinder or the pistons, replace the assembly.

Make sure that the bleed screw is not obstructed.

1. Protective boot
2. Bleed screw
3. Seal
4. Piston
5. Spring and washers
6. Cylinder body



33.



0,7 daNm



ADJUSTING FRONT WHEEL HUB

In order to adjust the front wheel hub roller bearing axial clearance, the nut fixing the bearings has to be tightened to a torque of 0.7 daNm and then loosened by 30° (as shown in the diagram below).

In these conditions the axial clearance should be 0.025 - 0.100 mm.





Diagram showing front wheel hub roller bearings axial clearance adjustment

- A. Corner of nut after tightening to a torque of 0.7 daNm.
- B. Reference mark on washer for loosening nut by 30°.




1874140002

1874140001




Staking nut fixing front wheel hub



Fitting front wheel hub cover

NOTE Before fitting smear the edge of the hub cap with TUTELA MR3 grease.

BLEEDING




P1V011D01

It is not advisable to reuse the brake fluid collected.

The level should be topped up with new brake fluid.


Front brake components available as spares




1. Brake back plate
2. Shoe return springs
3. Brake drum
4. Wheel nut and bolt for fixing drum to hub
5. Brake shoe

P1V011D02

33.




REMOVING-REFITTING



Removing-refitting brake drum


Before refitting the brake drum, remove any traces of rust from the contact surfaces




Fitting tool 1872257000 for retaining wheel cylinder piston whilst removing and refitting brake shoes

Removing-refitting brake shoe upper return spring

Removing-refitting brake shoe lower return spring




P1V013D01



P1V013D04

Removing-refitting brake shoe retaining pin




P1V013D02



P1V006D06


Removing-refitting brake shoes

The millings in the hub shown by the arrows should be facing the self-adjusting device in order to enable the brake shoe to be removed and refitted.




P1V013D03

33.




SHOES



Checking shoes


The minimum permissible thickness for brake shoes is 1.5 mm.



Removing-refitting brake shoe clearance self-adjusting device

Check that the self-adjusting device spring and washers are not worn or broken.


It is always advisable to replace the self-adjusting device circlip.



Checking and measuring brake drum



If the brake drums show signs of deep grooves or uneven wear, they should be skimmed. The maximum permissible diameter oversize for brake drums is 0.8 mm.

WHEEL CYLINDER



P1V015D01

Removing-refitting brake fluid pipe from wheel cylinder




P1V015D02

Removing-refitting bolts fixing wheel cylinder to brake back plate



Bleeding hydraulic system




P1V009D03

Removing-refitting and checking wheel cylinder components

When overhauling the seals and protective boots should always be replaced; if there are any anomalies in the cylinder body or the pistons, replace the assembly.


Make sure that the bleed screw is not blocked.

1. Protective boot
2. Bleed screw
3. Seal
4. Piston
5. Spring with washer
6. Cylinder body



P1V015D03

33.




P1V016D01



BLEEDING

It is not advisable to reuse the brake fluid collected.

The level should be topped up with new brake fluid.




P1V016D03



Cross section of rear wheel hub and brake drum

1. Wheel cylinder
2. Rear brake drum
3. Nut fixing flexible mounting and hub to wheel shaft




P1V016D02



Rear brake components available as spares

1. Brake back plate
2. Brake shoe return spring
3. Brake drum
4. Wheel nut and bolts for fixing drum
5. Rear wheel hub

HANDBRAKE



Handbrake components

1. Handbrake lever
2. Lever mounting
3. Push button for releasing handbrake lever
4. Toothed sector
5. Cable pulley
6. Cable outer casing
7. Shoe activating lever for handbrake
8. Cable return spring
9. Shoe activating lever pin



Check the operation of each component and check that the cable slides in its casing. If there are any signs of wear or hardening, replace the affected components.



1856109000

P1V017D02

Handbrake adjustment

From the rest position, pull the handbrake lever upwards through three notches. Adjust both tighteners until the rear wheels are locked; then, using spanner 1856109000, lock the tighteners using the lock nuts.

33.



Checking handbrake adjustment

NOTE When the adjustment has been carried out the handbrake lever should not go through more than 4 or 5 notches in the toothed sector and in the rest position the wheels should turn freely.

The arrow shows the handbrake warning light on.

Special tools

33.A

- 1856109000 Spanner (19mm) for adjusting handbrake control
- 1856132000 Spanner (10-11 mm) for adjusting brake fluid pipe unions
- 1872257000 Set of tools for retaining wheel cylinder pistons whilst fitting brake shoes
- 1881136000 Pliers for removing and refitting front and rear brake shoe return springs
- 1872278000 Tool for removing and refitting brake shoe clearance self-adjusting device

DESCRIPTION	Thread size	Tightening torque
		daNm


Front brake back plate to steering knuckle fixing, nut	M 8	2,9
Brake and clutch pedal mounting fixing, nut	M 8	1,5
Brake pump fixing, nut	M 8	1,5
Flexible pipe union on cylinder	M 10 x 1,25	2
Wheel cylinder.(front and rear) to brake back plate fixing, bolt	M 6	1
Rear wheel brake back plate and hub to track control arm fixing, nut	M 10 x 1,25	5,6
Rear wheel brake drum fixing, bolt	M 12 x 1,5	8,4
Handbrake mounting fixing, bolt	M 8	1,5

BATTERY

The specific gravity of the electrolyte (see table below) is dependent on the battery's state of charge.

Baumé degrees	s.g.	Battery charge:
32	1.28	100%
29	1.25	75%
26	1.22	50%
23	1.19	25%
20	1.16	nearly discharged
15	1.11	discharged

Measurements taken at a temperature of 15°C.



Measuring battery charge using a hydrometer



If the electrolyte level in one or more battery cells is below the minimum mark on the plastic container, top up with de-ionized distilled water.


ALTERNATOR

Checking maximum current output from alternator with integral electronic regulator, in the car:


Proceed as follows:

- disconnect the lead from the + B terminal of the alternator;
- insert an ammeter between this lead and the alternator's + B terminal;
- connect a voltmeter between the battery's negative pole and the lead connected to the alternator and ammeter (see diagram);
- start the engine and increase the speed to 3000 - 3500 rpm;
- switch on all available electrical devices one by one;
- measure the maximum current output when the voltage reading falls below 13.5 V.

If the ammeter's current reading is more than 5 A below the specified value, overhaul the alternator.



55.



Checking regulated voltage supplied by alternator, in the car

Maintain the connections and engine speed as stated above, then switch off a few devices until an absorption of approximately **half the maximum load** (20-25 A) is obtained.

Under these conditions, the voltage reading must be within the maximum and minimum values shown on the graph opposite, depending on the ambient temperature of the electronic regulator (alternator).

NOTE *With the alternator warmed up in an 80°C environment, the regulated voltage must reach 13.5 - 14.2 V.*

Checking regulation stability of electronic regulator

Maintain the same electrical connections and engine speed and switch on a few devices until a current absorption equivalent to 2/3 of the alternator's maximum output is obtained.

Under these conditions, the voltage must not drop by more than 0.4 V.


Then switch off a few devices until a current absorption of approximately 5 A is obtained; the voltage must not differ by more than ± 0.2 V from the reading taken at approximately half load.

If the voltage variation is not within the specified tolerance limits, the electronic voltage regulator is faulty and must be replaced.

Removing/refitting alternator

Proceed as follows:

- disconnect the battery's negative terminal and the alternator lead;
- slacken the alternator's bottom mounting bolt;
- slacken the alternator's top bracket bolt;
- manoeuvre the alternator to free it from the belt;
- remove the slackened bolts and withdraw the alternator from the engine compartment.



TENSIONING ALTERNATOR BELT

Slacken the alternator's bottom mounting nut. Slacken the top tensioning bracket nut.

Insert a lever between the alternator and the engine and tension the drive belt as necessary. Then tighten the two alternator nuts.


NOTE *The belt tension must be 30-40 daNm measured using tool 1895760000 or the new tool 1895762000.*

Wiring diagram

M. MARELLI ALTERNATOR OVERHAUL



Never start up the engine when there are temporary or slack electrical connections on the recharging circuit, since this could damage the alternator diodes. Never use test lamps for diagnostic checks on the electronic regulator, since it could be damaged.




M. Marelli AA125R-14V-45A alternator

NOTE *M. Marelli alternators are very similar in construction. The instructions and illustrations on the following pages apply to all of them.*

Before fully dismantling the alternator, carry out the operations and checks described below.


View of the alternator with rear cover removed

3. RTT 119A electronic voltage regulator.
4. 9-diode rectifier bridge.






Rear view of the alternator

Unscrew the nuts securing the rear cover (2) to the alternator and remove the rear cover.



55.




Checking continuity of the 3 stator windings

Connect the leads of an ohmmeter (set to a $1\ \Omega$ scale) to the ends of the three stator phases (a-b-c) in the three possible configurations as illustrated.

The resistance readings given by the instrument must be the same for all three measurements.




If the instrument needle does not move (infinite resistance) or reaches the end of the scale (no resistance), this means that the phase being measured is broken or in short circuit, in which case the stator must be renewed.





CHECKING DIODES

Disconnect the excited diode wiring connector (1) from the positive brush spade connector.



Unsolder the terminals (2) of the stator windings from the rectifier bridge.





Checking exciting diodes

Connect an ohmmeter lead to connector (1). The instrument's second lead should be placed in contact with each of the three terminals (A-B-C) in turn.



Reverse the instrument's lead connections and repeat the three measurements.

Checking positive power diodes

Connect an ohmmeter between the alternator's positive terminal (X) and each of the three terminals (A-B-C) in turn. Reverse the instrument's lead connections and repeat the three measurements.


**Checking negative power diodes**

Connect an ohmmeter between the negative diode assembly (Y) and each of the three terminals (A-B-C) in turn. Reverse the instrument's lead connections and repeat the three measurements.



The instrument should give a resistance reading for each of the terminals (A-B-C) in the tests described above.

When the instrument's leads are reversed, the pointer should not move. If the pointer moves for both connection configurations (diodes in short circuit), or does not move at all (broken diode), the complete rectifier bridge should be renewed.


ROTOR**Checking rotor resistance measured between the brush spade connectors**

Disconnect the excited diode wiring connector (1) from the positive brush spade connector.

Connect an ohmmeter (set to a $1\ \Omega$ scale) between the two spade contacts on the brush holder/voltage regulator support.


If the resistance reading given by the instrument is different from that specified, or is infinite (broken circuit), the rotor will need to be checked and possibly renewed.

55.



Dismantling


Whilst holding the alternator shaft still with a suitable Allen key, unscrew the nut securing the fan and pulley to the rotor. Slide the fan, pulley, spacers and washers off the alternator shaft.



Disconnect the excited diode wiring connector (2) from the positive brush spade connector.

Unscrew the bolts (3) securing the electronic voltage regulator (4) complete with brushes to the alternator rear end plate.

Unscrew the nuts (5) and remove the bolts holding the alternator's main external components.




Electronic voltage regulator


- a. Brushes
- b. Spade connectors

Dismantle the various components (as illustrated), remembering that some pressure must be exerted on the rotor shaft to free the rotor (7) from the front mounting plate (6).


NOTE *If a press is not available, use a brass drift to avoid damaging the thread.*



F1M07ZL01







F1M07ZL02



F1M07Z

Move the rectifier bridge (10) away from the rear mounting plate and unsolder the terminals (11) of the stator windings.

55.



Dismantle the stator (12) and its terminals (11) from the rear mounting plate (8).

Checking rotor insulation

Connect an ohmmeter (set to a $1\ \Omega$ scale) between a slip ring and the rotor casing (see arrows). The instrument should give an infinite resistance reading; if not, the rotor should be renewed.

Checking rotor resistance between the slip rings


Connect an ohmmeter (set to a $1\ \Omega$ scale) between the rotor's slip rings (see arrows); the instrument reading should show some resistance. If the instrument's resistance reading is different from that specified, or is infinite (broken circuit), the rotor will have to be renewed.



Check that the bearing moves freely and noiselessly with no tight spots. Check that there are no hollows on the slip rings caused by the brushes, otherwise the complete rotor should be renewed.

Reassembly


To reassemble, simply reverse the procedure for dismantling.

**DISMANTLING Z.E.M. A 115 - 14 V - 43 A
ALTERNATOR**


P1V009L01

Dismantled alternator

1. Rear cover
2. 15TR b electronic voltage regulator



P1V009L02




P1V009L03

**Alternator (diode assembly end) and brush
holder**

3. Diode assembly
4. Brush holder
5. Brushes


55.



Dismantled alternator

- 6. Alternator housing (drive end)
- 7. Rotor
- 8. Alternator terminal (+ B)
- 9. Stator windings


View of pulley components - Z.E.M. A 115 - 14 V - 43 A alternator



Never start the engine when there are temporary or slack electrical connections on the recharging circuit, since this could damage the alternator diodes. Never use test bulbs for diagnostic checks on the electronic regulator, since it could be damaged.

DISMANTLING Z.E.M. R 76 A 0.6 KW - 12 V STARTER MOTOR


Before overhauling the starter motor, make sure that the insufficient starting power is not caused by low battery charge.



P1V011L01

Starter motor components

1. Field coils
2. Armature
3. Pinion and clutch assembly
4. Drive end housing
5. Solenoid
6. Commutator end housing and brush holder
7. Pinion actuating fork
8. Pin



P1V011L02

Checks


Carry out the following tests on the starter motor components:

armature: continuity, short circuit and earthing


field coils: continuity and earthing

brush holder: earthing

solenoid: continuity and earthing



P1V011L03



Bench testing the starter motor

The starter motor must be tested on a bench equipped with a hydraulic brake. Secure the starter motor to the test bench, connect it to a direct supply then carry out three tests: operation, engagement and no load. Measure the current absorption, torque, speed and voltage for each test.



The current absorption measurement must refer to the motor only, without the solenoid, so on the test bench the ammeter must be connected as illustrated in the diagram.

STARTER MOTOR FAULT DIAGNOSIS

1. The motor will not turn

Possible causes:

- battery terminals and/or connectors corroded;
- starter motor supply cable terminal and/or connector corroded;
- starter motor supply cable terminal broken or corroded;
- battery fully discharged;
- no contact between brushes and commutator;
- positive brush short-circuited;
- starter switch contacts corroded, worn or insulated by fragments of material;
- armature or field coil earthed;
- armature or commutator centrifuged.

2. The motor turns very slowly

Possible causes:

- commutator blades and brushes worn;
- some of the armature or field winding coils short-circuited;
- battery terminals and connections corroded;
- battery charge very low, or one or several cells damaged.

3. Excessive noise on starting

Possible causes:

- pinion clutch assembly worn;
- motor incorrectly aligned with flywheel;
- some flywheel teeth excessively worn on engagement side.

COMPONENTS AND OPERATION OF THE IGNITION SYSTEM

The ignition system comprises:

- distributor with no cap or rotor
- coil with two high tension connections
- resistive wire
- spark plugs


The coil comprises a primary winding connected at one end to the distributor, and at the other end to the battery's positive terminal, via a resistive wire and switch.

The secondary circuit has two terminals which send high tension to the spark plugs whenever the contact breaker points open.


Because of how the secondary circuit is closed (spark plugs located in series), the high tension supplying the plugs will be of varying intensity.

This is due to the fact that one of the two plugs will periodically be under higher pressure (compression stroke) than the other (exhaust stroke).

Since the current has to overcome a higher dielectric in the plug at the compression stroke, it will produce a brighter spark in the latter, while in the other plug the spark will be insignificant.



P1V013L01






P1V013L02

Location of ignition coil in car

1. High tension leads
2. Terminal -1 (lead coming from distributor)
3. Terminal +B (lead coming from ignition switch)
4. Ignition coil

55.



Components of the Zelmot 3459 A distributor

1. Distributor body with shaft and centrifugal weights
2. Vacuum advance diaphragm
3. Condenser
4. Contact breaker points
5. Fixed plate
6. Moving contact breaker plate
7. Dust cover

CONTACT BREAKER ADJUSTMENT

Zelmot 3459 A distributor

1. Fixed contact breaker plate screw
2. Feeler gauge

M. Marelli S 314 A distributor

1. Allen key for contact breaker adjustment (turn key to vary points gap)
2. Feeler gauge

Contact breaker points gap

M. Marelli	Zelmot
0.37 - 0.43	0.47 - 0.55

FITTING DISTRIBUTOR AND IGNITION TIMING




Before fitting the distributor, rotate the engine clockwise until the reference mark (1) lines up with the first of the notches (2). Remove the distributor dust cover (3) and rotate the shaft until the contact breaker points are just beginning to open. Then press the distributor into its housing.

Disconnect the vacuum pipe from the vacuum unit and obstruct it.


Connect a stroboscopic lamp, start the engine and run it at 750-800 rpm, then check using the lamp that the mark on the pulley lines up with the first notch on the plate.

To obtain the correct advance position, rotate the distributor in its housing, then tighten it. The ignition timing at idle thus obtained is 10° before T.D.C., i.e. the specified value.

Reconnect the vacuum pipe to the vacuum unit and disconnect the lamp.




Angles of advance on engine




Graph showing automatic advance of distributor on engine

Angles of advance on engine



Graph showing vacuum advance of distributor on engine

55.



REMOVAL-REFITTING



Removing switch panel bolts



Withdrawing switch panel



The top of the panel slots into its frame.



Removing instrument panel bolts

Removing instrument panel from the fascia


- disconnect the speedometer cable from the instrument panel
- disconnect all the electrical connectors from the instrument panel



P1V017L01

Front of instrument panel


- A. Trip recorder
- B. Speedometer
- C. Odometer
- D. Trip recorder reset button
- E. Fuel gauge
- F. Water gauge
- G. Warning lights



P1V01ZI02

Rear view of instrument panel with terminal strips for connecting up the car's electrics

NOTE *The terminals and terminal strips are identified by the same numbers and letters as those used on the wiring diagrams.*




P1V017L03

55.

CONNECTOR A		
A	1	+ from ignition switch
HG	2	Low oil pressure warning light, from oil pressure warning sender
NZ	3	Low battery charge warning light: from + D alternator terminal
SN	4	Hazard lights indicator: from hazard lights flasher unit
VN	5	Main beam warning light from fuse F6 in the fuse holder
GR	6	Parking lights warning light: from cigar lighter illumination bulb
-	7	Free
-	8	Free



CONNECTOR B		
HR	1	Fuel reserve warning light: from fuel gauge control
BN	2	Low brake fluid level warning light: from low brake fluid level sender
AN	3	+ from fuse holder: from fuse D4
HN	4	Low water level warning light: from low water level sender
N	5	Earth cable, to multiswitch
AG	6	Fuel gauge: to fuel gauge control

CONNECTOR C		
VB	1	Water temperature gauge: from water temperature sender
-	2	Free
-	3	Free
M	4	Heated rear window warning light: from heated rear window switch
V	5	Rear fog lamp warning light: from rear fog lamp switch
AR	6	Direction indicators warning light: from direction indicators intermittent switch on fuse holder



Wiring diagram of instrument panel

SWITCH PANEL – Rear view with terminal strips for connectors




Fascia wiring connections to the car's electrics

	MB + from fuse holder B To electric fan motor - 1st speed Z To electric fan motor - 2nd speed		N + from ignition switch INT terminal N + to headlight flasher on multiswitch M + from ignition switch 30 B + to fuse holder V + to lights multiswitch
	V To rear fog lamp + supply cable V To instrument panel warning light H + from fuse holder branched from right dipped beam headlamp wire		AN + direction indicators intermittent switch supply AB + from fuse holder (fuse 4) AB + to braking lights switch Z + from fuse holder (fuse 1) ZB + to courtesy light R + to hazard lights intermittent switch
	SN + to rear window washer pump AN + from fuse holder RN + to rear window wiper motor		A + from fuse holder M + to heated rear window M + to instrument panel warning light


55.

LOCATION OF FUSE AND RELAY HOLDER




1. Direction indicators
2. Windscreen wiper intermittent switch
3. Radiator cooling electric fan relay
4. Horn relay

Fuse symbol	Fuse number	Protected circuits
⚠	A-1	Hazard lights and warning light - Courtesy light - Horn
⚡	B-2	Heated rear window and warning light
🕒	C-3	Radiator cooling fan
↔ ↔	D-4	Direction indicators and warning light - Braking lights - Handbrake warning light - Fuel gauge
☰	E-5	Left main beam headlamp
☰	F-6	Right main beam headlamp and warning light
	G-7	Free
☰	H-8	Right dipped beam headlamp and warning light - Rear fog lamp and warning light
☰	I-9	Left dipped beam headlamp
	L-10	Free
☰	M-11	Front left parking light - Rear right parking light - Parking lights warning light - Number plate light and instrument panel light
☰	N-12	Front right parking light - Rear left parking light
	O-13	Fast idle solenoid
SERVIZI	P-4	Windscreen wiper and intermittent switch - Windscreen washer pump - Rear window wiper - Rear window washer pump
🕒	Q-15	Car interior fan - Reversing light




Front view of fuse holder and symbols of the main protected circuit




Rear view of fuse holder and colours of fuse and relay input cables

RADIATOR COOLING FAN



Location of components

1. Radiator cooling fan motor
2. Two-stage thermal switch
3. Additional resistor
5. Fast idle solenoid



Location of fast idle solenoid

COMPONENT SPECIFICATIONS

Electric fan motor (1)

With a 12 V supply, it should run at 3000 ± 100 rpm.
Power 110 W

Additional resistor (3)

$0.30 \pm 0.05\Omega$

Thermal switch (2)

	96 - 100°C	101 - 105°C
	90 - 94°C	95 - 90°C

55.


Operation

A two-speed radiator cooling fan is fitted on the new 126 BIS versions. The fan (1) is controlled by the two-stage thermal switch (2). When the coolant temperature reaches 95-97°C, the first contact a) closes, the thermal switch earths the exciting circuit of the relay (4) and current passes through resistor (3), supplying the fan (1) and enabling it to operate at the first speed.

When the coolant temperature reaches 103-105°C, contact b) of the thermal switch (2) also closes, so the fan is directly earthed and the second operating speed is enabled.


In addition, to counteract the reduction in engine speed caused by the extra power absorption after the fan's entry into operation, a fast idle solenoid is fitted (5). This is excited when the thermal switch (2) closes and allows the vacuum in the inlet manifold to come into contact with a diaphragm device mounted on the carburettor, which increases the throttle valve aperture and so makes up for a drop in engine speed.

Wiring diagram




1. Radiator fan
2. Two-stage thermal switch
3. Additional resistor
4. Relay
5. Fast idle solenoid

Starting - Ignition - Recharging (see legend on p. 29)




55.

Parking lights and warning light - Dipped beam headlamps - Main beam headlamps and warning light - Headlamp flasher - Number plate light - Reversing light - Rear fog lamp and warning light (see legend on p. 29)




Horn - Windscreen wiper - Windscreen washer pump - Courtesy light - Rear window wiper - Rear window washer pump - Heated rear window (see legend on p. 29)




P1V025L01

55.

Direction indicators and warning light - Hazard lights and warning light - Braking lights (see legend on p. 29)




Radiator cooling fan - Car interior fan - Radio arrangement - Fuel gauge and reserve warning light - Low water level warning light - Low oil pressure warning light - Water temperature gauge (see legend on p. 29)



P1V027L01

55.

Parking lights and warning light - Dipped beam headlamps attenuated with DIM-DIP device - Main beam headlamps and warning light - Headlamp flasher - Number plate light - Reversing light - Rear fog lamp and warning lamp (see legend on p. 29)



P1V028L01


00200	Alternator with integral regulator
00500	Battery
01000	Starter motor
01206	Windscreen wiper motor
01207	Rear window wiper motor
01400	Windscreen washer pump
01401	Rear window washer pump
01500	Radiator cooling fan
01504	Car interior fan
02210	Fast idle solenoid
02400	Ignition coil
02475	Distributor
02500	Spark plugs
03000	Low oil pressure sensor
03006	Handbrake warning light control button
03007	Brake pedal braking lights switch
03008	Reversing light switch
03036	Radiator cooling fan two-stage thermostatic switch
03060	Rear fog lamp switch
03110	Heated rear window switch
03114	Car interior fan switch
03302	Courtesy light control button
03315	Windscreen washer pump control button
03319	Horn push
03500	Ignition switch
03550	Hazard warning lights switch
03552	Exterior lights switch
04010	Direction indicators control
04020	Main beam and dipped beam headlamps control
04032	Windscreen wash/wipe control
04225	Radiator cooling fan relay
04237	DIM-DIP circuit relay
04291	Horn relay
04441	DIM-DIP circuit exclusion switch
04500	Windscreen wiper intermittent switch
04570	Hazard lights intermittent switch
04581	Direction indicators intermittent switch
04700	Water temperature sender
05008	Front right lights cluster
05009	Front left lights cluster
05410	Front right direction indicator cluster
05411	Front left direction indicator cluster
05412	Right side repeater
05413	Left side repeater
05630	Reversing light
05640	Number plate light
05650	Rear fog light
05660	Rear right light
05661	Rear left light
06005	Ceiling courtesy light
06084	Instrument illumination bulbs
06300	Parking lights warning light
06305	Main beam headlamps warning light

06310	Rear fog lamp warning light
06315	Hazard lights warning light
06320	Direction indicators warning lamp
06337	Handbrake and brake fault warning light
06340	Low water level warning light
06343	Low oil pressure warning light
06345	Fuel reserve warning light
06355	Low alternator charge warning light
06800	Horn
07000	Low water level warning light switch
07003	Brake fluid level sensor
07050	Fuel gauge and reserve warning light control
07060	Idle cut-off solenoid
07400	Fuel gauge
07415	Water gauge
09000	DIM-DIP system dropping resistor
09008	Radiator fan speed adjustment dropping resistor
09100	Heated rear window
41000	Connection
41001	Connection
41002	Connection
41003	Connection
41004	Connection
41005	Connection
59000	Cigar lighter
59010	Radio
60000	Instrument pane
60230	Fuse holder junction unit
70100	Front left earth point
70101	Front right earth point
70108	Rear earth point
90033	Junction point


Cable colour codes	
A	Light Blue
B	White
C	Orange
G	Yellow
H	Grey
L	Dark Blue
M	Brown
N	Black
R	Red
S	Pink
V	Green
Z	Purple
AB	Light Blue-White
AG	Light Blue-Yellow
AN	Light Blue-Black
AR	Light Blue-Red
AV	Light Blue-Green
BG	White-Yellow
BL	White-Dark Blue
BN	White-Black
BR	White-Red
BV	White-Green
BZ	White-Purple
CA	Orange-Light Blue
CB	Orange-White
CN	Orange-Black
GN	Yellow-Black
GL	Yellow-Dark Blue
GR	Yellow-Red
GV	Yellow-Green
HG	Grey-Yellow
HN	Grey-Black
HR	Grey-Red
HV	Grey-Green
LB	Dark Blue-White
LG	Dark Blue-Yellow
LN	Dark Blue-Black
LR	Dark Blue-Red
LV	Dark Blue-Green
MB	Brown-White
MN	Brown-Black
NZ	Black-Purple
RB	Red-White
RG	Red-Yellow
RN	Red-Black
RV	Red-Green
SN	Pink-Black
VB	Green-White
VN	Green-Black
VR	Green-Red
ZB	Purple-White

Position the car on ramps. Proceed as follows:

- disconnect the battery's negative lead (under the bonnet);
- open the tailgate, remove the trim and fold down the rear seat squab;
- drain the coolant





- Disconnect the water temperature sender wire





- Disconnect the water hose between the cylinder head and radiator/heater

- Disconnect the water hose between the cylinder head and cooling radiator

- Disconnect the petrol inlet pipe




- Disconnect the petrol return pipe to the tank



- Disconnect the spark plug supply leads

- Disconnect the fast idle vacuum connection from its capsule




- Disconnect the carburettor fast idle vacuum connection

- Disconnect the distributor vacuum connection cable


- Disconnect the accelerator linkage

- Disconnect the choke cable


10.





– Disconnect the clutch cable



– Disconnect the alternator wiring




– Disconnect the distributor supply lead




– Fit crossbar 1870414000 and support the engine with the special hook (as shown in the photo opposite)




- Raise the car and dismantle as follows:



- Disconnect the left driveshaft




- Disconnect the right driveshaft



- Remove the engine cooling radiator air duct guard

- Disconnect the water hose between the cylinder head and thermostat




- Disconnect the water hose between the radiator/heater and thermostat

- Disconnect the water hose between the cooling radiator and thermostat



- Disconnect the low oil pressure sender wire

10.


- Disconnect the starter motor supply wire




- Disconnect the earth lead




- Detach the gearbox support crosspiece from the body



- Remove the starter motor guard




- Remove the gear control rod from the gearshift lever





- Disconnect the reversing switch wire the light

- Disconnect the speedometer cable


- Lower the ramps and disconnect the following:




– Remove the bolts securing the rear valance to the top rear cross-member



– Disconnect the reversing light and fog lamp electrical connections






– Remove the 4 nuts securing the rear valance to the body (side)



- Fit the universal hook 1860592000 to the power unit using the special attachment brackets, then hoist the unit until it is under slight tension and remove the crossbar


10.

- Disconnect the engine mounting from its anchor bracket





P1V006J04

Engine mounting




Rear valance complete with bumper and lights



- Lower the power unit to the ground and unhook the hoist
- Raise the ramps and withdraw the power unit


- rest the power unit on a platform and remove the following parts:



NOTE To refit the power unit, simply reverse the order of removal.




Clutch pedal height

ENGINE LONGITUDINAL SECTION




PX001P401

10.


Exhaust manifold




Weber 30 DGF 3/150 carburettor with gaskets and mount




Engine coolant line
connecting cylinder
head fitting to exhaust
manifold





Fuel delivery line
from pump to carburettor





Fuel pump complete with seals, washers and control
rod



Ignition breaker




Intake manifold and gasket




Tappet cover



Cylinder head fitting for coolant line attachment complete with temperature transmitter




Oil level dipstick





Alternator



PX003P406




10.






Cylinder head



Rocker shaft and rods




Engine bearing




Centrifugal filter cover

Deflector


Coolant pump cover





Thermostat






Bracket connecting alternator to engine block



Timing cover





Deflector




Lock flywheel in position to remove hollow screw



10.




Coolant pump impeller




Low oil pressure transmitter



Oil sump complete with oil pump drive shaft, oil pump, coolant pump drive shaft and pump intake





Camshaft drive





Camshaft


Main bearing, flywheel end




Flywheel




Drive shaft



Tappets





Pistons



Main bearing, camshaft end



10.



NOTE *Thoroughly check all parts once disassembly is complete.
The following sections contain instructions for main checks and measurements necessary for determining whether components can be reused.
Proper assembly sequences and procedures are shown in addition to tools for engine assembly.*

CYLINDER LINERS

80,000 ÷ 80,030



Cylinder liners are bonded to engine block with LOCTITE 640.



Cylinder liner measurement check and diagram

Measure maximum cylinder liner ovalisation, taper and wear values
Visually inspect all sliding surfaces

NOTE Permitted tolerances are: taper - difference between 1st and 3rd measurement: ± 0.005 mm; ovalisation - difference between a and b: ± 0.05 mm.



Replacement cylinder liners are not supplied individually. If one cylinder liner is defective, the entire engine block must be replaced




PX009P403

ENGINE BLOCK

\varnothing_1	22,015 ÷ 22,036
-----------------	-----------------

\varnothing_2	43,020 ÷ 43,045
-----------------	-----------------




Camshaft seat check

NOTE Internal surfaces must be smooth and unscored


Use an internal gauge to test for wear
The engine block should be replaced if significant defects are found

10.




Tappet seat check

Measure amount of wear. Remember that replacement tappets can be supplied with diameters increased by 0.05 and 0.10 mm



Bore seats to fit larger tappets




Check engine block caps

Check that caps are oil tight. Replace any caps found to be defective.




Spread sealant on engine block contact surfaces before fitting caps



PX011P401

Stud removal - assembly

10.




CRANKSHAFT

	\varnothing_1	$53,970 \div 53,980$
	\varnothing_2	$53,980 \div 53,990$

Journal measurement

Diminution classes are: 0.2 - 0.4 - 0.6 - 0.8 - 1.00 mm.

NOTE *Check journal and crank pin diameters. If measurements exceed permitted tolerances, grind to correct diameter.*




	$44,000 \div 44,020$
--	----------------------

Crank pin measurement

Diminution classes are: 0.254 - 0.508 mm.




Clean lubrication ports thoroughly with petrol before grinding pins and journals.



Cap closure

Squeeze caps closed at points arrowed.




PX013P401

Disassembly of clutch shaft centring bushing


The bushing may be fitted using an ordinary driver

MAIN BEARINGS

\varnothing_1	54,010 \div 54,025	
\varnothing_2	54,020 \div 54,035	




PX009P401



PX013P402

Main bearing measurement


Diminution categories are as follows: 0.2 - 0.4 - 0.6 - 0.8 - 1.0 mm.



PX013P403



Drive shaft assembly

10.




Assembly of crankshaft end main bearings and oil seal

The arrows indicate screws to be tightened in pairs




Installation of seal on main bearing, flywheel end

An ordinary driver may be used for installation and removal operations




Installation of main bearing, flywheel end

The arrows indicate screws to be tightened in pairs



FLYWHEEL



PX015P401

Check clutch plate seat


Face surface if scoring is present

NOTE If the crown wheel is to be replaced, first heat the new crown wheel to 80°C in an oven, then fit on flywheel with inside beveled edge facing the flywheel

Use an ordinary steel driver for assembly




4,4 daNm



1860161000


PX015P402



1860449000

PX015P403


Installation of threaded dowels for drive shaft positioning



CON ROD - PISTON ASSEMBLY





Piston ring disassembly



Piston crown cleaning

1860212000




Gudgeon pin retaining ring
disassembly

Gudgeon pin disassembly


NOTE *Parts may be re-used if found to be free of wear. Care must be taken, however, to mark parts from the same unit.*

PISTONS

A	$79,950 \div 79,960$
C	$79,960 \div 79,970$
E	$79,970 \div 79,980$



PX017P401



PX017P402


Measurement of piston diameter

- **Standard:** nominal measurements selected in five 0.01 mm categories
A - B - C - D - E
spares only A - C - E
- **Oversized:** 0.4 mm
without selection of diameter and category on pin hub hole.

NOTE *The arrows indicate areas from which excess material must be removed to obtain equal weights.*

A = Letter indicating piston category


$\pm 5 \text{ g.}$



PX020P401

Check piston weight meets specifications


$0,040 \div 0,060$



PX017P404

Check piston and cylinder liner mating clearance

10.




GUDGEON PINS



$19,990 \div 19,994$

Gudgeon pin diameter measurement
Pins are supplied as standard spares




It should be
possible to
press-fit pin nor-
mally

Pin should not
tend to slip out of
hub



Conditions for proper pin-piston mating




PISTON RINGS



1	$1,478 \div 1,490$
2	$1,978 \div 1,990$
3	$3,925 \div 3,937$

Piston pin thickness measurement

1	0,045 ÷ 0,077
2	0,040 ÷ 0,072
3	0,030 ÷ 0,062



PX019P401


Check mating clearance between piston rings and piston crown

1	0,30 ÷ 0,45
2	0,20 ÷ 0,35
3	0,20 ÷ 0,35



PX019P402


Check and measure clearance between ends of piston rings



PX019P403

Dress ends of piston rings

Piston rings are also supplied oversized by 0.4 mm.




CON RODS

Check con rods are equal in weight




If con rods are replaced, the relevant cylinder number must be stamped on the half bearing seat.




Area from where material may be removed

The arrow indicates the area from where material must be removed to balance weights, according to type of con rod.




Check con rod alignment




PX021P401

Connecting rod alignment



PX021P403

Milling small end



PX021P402


Removal-installation on small end



Before dressing the bushing, make a notch on the old bushing at the point of the milling on the small end.




20,000 ÷ 20,006



PX021P404

Dressing of bushing press-fitted to small end




Con rod cylinder number



Con rod - piston assembly diagram



If the con rod is replaced, the relevant cylinder number must be stamped on the half bearing seats.



PX022P403



Fit pin to con rod - piston assembly

Lock gudgeon pin in seat with retaining ring.



PX016P401



Fit and position rings on pistons

Fit piston rings with wording "TOP" uppermost.

Following assembly, position piston ring ends so that they do not coincide with the pin centre line and are staggered by about 120°




Installation of con rod half bearings

NOTE Spare con rod bearings are supplied with inside diameter decreased by 0.254 - 0.508 mm.



*Do not try to adapt half bearings. Replace component if signs of scoring or binding are found.
Clean parts thoroughly before installation.*



PX023P401




Diagram showing proper installation of con rod - piston assembly in cylinder liner

The arrow shows the direction of rotation of the engine from the camshaft end.




When installing the con rod - piston assembly, check that the number of the relevant con rod is turned towards the camshaft.




Install con rod - piston assembly in cylinder liner



Components before final installation with engine oil.




PX023P403



CRANK PIN CLEARANCE MEASUREMENT




Apply edge of plastigage to crankpins
The gauge edge is arrowed



3,4 daNm



Tighten con rod cap retaining bolt nuts in pairs



0,024 ÷ 0,074


Measure clearance between pins and con rod bearings using special gauge




Components prior to final assembly
with engine oil


Tighten con rod cap screws in pairs

View of con rod - piston components, supplied as spares



Set of seals and gaskets for engine overhaul





PX026P401




CAMSHAFT



\varnothing_1 **21,979 ÷ 22,000**

\varnothing_2 **42,975 ÷ 43,000**




PX026P402



5,868




5,868



PX026P403

Camshaft journal measurement

NOTE *Cam and journal surfaces must not show signs of binding or scoring. Replace camshaft if this is the case.*



PX026P404




Camshaft installation



components with engine oil prior to final installation

CAMSHAFT DRIVE




Camshaft drive check



Do not replace camshaft drive components individually (chain, driving gear and driven gear).





1 daNm



Installation and tightening of camshaft drive




NOTE *Line up the reference marks on the two gears during timing adjustment (the reference marks are arrowed).*



Installation of seal on timing cover


Use an ordinary driver for installation and removal operations.
Oil seal with engine oil prior to installation.

10.




Installation of timing cover and seal

Screws securing timing cover to engine block are arrowed.



Installation of engine mounting bracket and torque tightening of screws





Installation of alternator drive pulley, deflector, lock washer and hollow screw

Torque tightening of hollow screw



Before tightening hollow screw, drive shaft rotation must be blocked using tool 1860161000 (flywheel retainer) so that lock washer may be secured.





PX029P401

PX029P402

Deflector installation

Fit deflector to hollow screw after securing lock washer




PX029P403

Centrifugal filter cover installation

Line up mark on centrifugal filter cover with mark on alternator drive pulley for more convenient assembly


10.



OIL PUMP





Accessory shaft drive gear installation-removal



Installation-removal of oil suction filter with built-in control valve

Arrows indicate screws to be removed



Oil suction strainer with built-in control valve





Check that oil suction filter and sump mating surfaces are flat and not scored or pitted. Thoroughly clean components during assembly.





Before assembly, check that oil pressure regulation spring is loaded to 2.35 - 2.45 daN for a height of 36 mm, or 4.29 - 4.54 daN for a height of 29 mm.

Cross section of accessory shaft




Removal-installation of accessory shaft and oil pump driven gear




Check that oil pump housing (in sump) does not show signs of wear or damage.

10.




0,080 \div 0,189

Check clearance between pump seat and driven gear



0,025 \div 0,100

Check clearance between driving gear and driven gear




0,045 \div 0,120

Check clearance between pump cover support and top end of pump gears




If clearances are not as specified replace oil sump, accessory shaft and driven gear.




2

PX033P401



3

PX033P402



1

PX033P403




3

\varnothing_1	$15,989 \div 16,000$
\varnothing_2	$11,901 \div 11,913$
\varnothing_3	$15,970 \div 15,985$

ACCESSORY SHAFT

Accessory shaft journal measurement


NOTE *Oil pump driving gear and journal surfaces should not show signs of binding or scoring. Replace accessory shaft if this is the case.*






1840207813






Remove coolant pump packing box and remove oil pump seal




Check that coolant pump seat (in sump) does not show signs of wear or damage.





Installation of oil pump seal (1) on sump



Installation of coolant pump packing box on (1) oil sump




Installation of accessory shaft drive gear (1) and oil sump gasket (2)




Installation of oil sump complete with accessory shaft and oil pump driven gear

Spares supplied for lubrication and coolant systems




10.

ENGINE CROSS SECTION




PX036P401


DISASSEMBLY AND CHECKS




Removal of lock cones, cups, springs and valves



Descaling and cleaning of valve seats and ports





VALVES




Valve descaling

Check that the valve stem does not show signs of scoring or binding. Also use micrometer to check that valve stem meets specified measurement values.

VALVE GUIDES**Valve guide disassembly****Valve guide assembly**

Spare valve guides are available with outer diameter oversized by 0.05 - 0.10 - 0.25 mm.

NOTE *Before fitting new valve guides, heat cylinder head to 100°C - 120°C.*

**Boring inner surface of valve guide**


Carry out in case of slight distortion during press-fitting




L = Valve seat ground at 45° to specified width

Reface valve seats on cylinder head


NOTE Reface valve seats on cylinder head every time valves and valve guides are refaced or replaced.




Grinding of valve seats with wheel at $44^\circ 30'$



Reduction of valve seat at top with wheel at 20°




Reduction of valve seat at bottom with wheel at 75°



Measurement of valve abutment line in seat

NOTE If contact is not centred on valve stem head, grind cylinder head seats as necessary. If centring is not possible, replace valve seat.



Valve seal pressure testing




Fit spark plugs before carrying out test.

VALVE SPRING

	P ₁	27.7 - 31.2 daN
	H ₁	39 mm
	P ₂	61.0 - 66.7 daN
	H ₂	29.3 mm

Check valve spring load

NOTE *Spring must be checked before installation to ensure load is as specified.*




Installation of oil seal on valve guide




components with engine oil prior to final installation.


The pictures are numbered to indicate correct installation sequence.



1




2




1860691000

3



4

PX043P406



Installation of valve, cups, spring and valve lock cones



parts with engine oil prior to final assembly

Valve gear parts supplied as spares



Adjustment
screw nut

Lock cones


Bottom cup

Valve spring

Top cup

Oil seal

Valve guide




Valve clearance ad-
justment screw

Rocker rods

Tappets

Camshaft




PX044P402

TAPPETS



21,978 ÷ 21,996




PX045P401

Tappet diameter check

NOTE *Tappets should be replaced in the case of ovalisation or binding on diameter, or binding of surfaces in contact with cam shaft throws.*

Tappets are also available oversized by 0.05-0.10 mm.




PX045P402

Installation of tappets in engine block




components with engine oil prior to final assembly.



PX045P403

Installation of cylinder head gaskets


NOTE *Position cylinder head gasket on engine block. Ensure "ALTO" mark is positioned at top.*



CYLINDER HEAD TIGHTENING




Installation of cylinder head



4,9 daNm



Diagram to show
tightening order
of screws re-
taining
cylinder
head to engine
block




PCX046P404

Torque tightening of cylinder head to engi-
ne block




*Tighten cylinder head in two stages:
first tighten bolts to a torque of 2.5
daNm, then to 4.9 daNm.*



3 daNm




Torque tightening of screws retaining
cylinder head to engine block




Installation of rocker control rods

Rods should not show signs of distortion or wear on contact surfaces. Replace them if this is the case.

Check that oil delivery port to rocker shaft (arrowed) is not obstructed.




ROCKER SHAFT




Removal - checking - installation of rocker shaft

Arrowed surfaces must be perfectly smooth. Replace part if pitting is found.

Inner surfaces must not show signs of binding or ovalisation. Replace them if this is the case.




10.



1850089000

PX048P401

Installation of rocker shaft and torque
tightening of support retaining screws




TAPPET CLEARANCE ADJUSTMENT

0,15 mm ± 0,05



0,15 mm ± 0,05

Valve-rocker clearance adjustment




Installation of gasket and tappet
cover


Installation of gasket and intake manifold




Installation of spark plugs




Installation of carburettor gaskets and plate






**Installation of carburettor with engine on
bench**




**Removal - installation of carburettor with
engine on car**

Use 10 mm wrench no. 1852151000 if carburettor is to be removed when engine is in car.

WEBER 30DGF 3/150 CARBURETTOR



Accelerator pump
Pneumatic diaphragm
Protective cover and idle adjustment screw
Primary throttle adjustment screw





Fast idle casing
Primary throttle adjustment screw
Protective cover and idle adjustment screw

NOTE Completely disassemble carburetor, then check all adjustable parts (main jet, idle jet, emulsion tube etc.). These parts must be calibrated to values specified for the type of carburetor. To thoroughly clean all carburetor components, dip in an appropriate solvent and blow with compressed air. Do not use metal points or wire to clean jets. Renew all gaskets, seals and rings at each overhaul. Check needle valve seat seal, main throttle spindle clearance and manifold support surface flatness.




10.

CHECKING AND ADJUSTMENT OF PRIMARY THROTTLE PARTIAL OPENING



With the throttle control lever in the position indicated, i.e. in contact with the link (without forcing the link), the primary throttle should be open to a gap of 4.7 ± 0.25 mm (distance X). Adjust link as necessary if required.




CHECK FULL THROTTLE OPENING



Check full throttle opening

With the throttle control lever pulled completely back until the stop rests against the sector, throttles should be fully open and leave a gap of 14 ± 0.5 mm (distance X).

MANUAL CHOKE





Checking and adjustment of primary throttle opening (for idle)

When the choke is fully out, the starter throttle should close while the primary throttle should open to a gap of 0.85 » 0.90 mm (distance Y). If the primary throttle opening is not as specified, alter the adjustment linkage.





Measure distance Y from the side where the throttle opens into the port (progression hole side).

Adjustment of pneumatic diaphragm



10.



NOTE Create a vacuum in the pneumatic diaphragm delivery port (located in the base), and check for leaks in the circuit.


Replace the diaphragm if leaks are found.

Checking and adjustment of secondary throttle opening

When the choke control lever is pulled completely back, the secondary throttle should open to a gap of 3.5 - 4 mm (distance X) with test vacuum downstream of primary throttle. If the secondary throttle opening is not as specified, correct via the adjustment screw.



Measure the distance from the side where the throttle opens into the port.



ACCELERATOR PUMP - flow check

NOTE Fill the carburettor float chamber with petrol and operate the main throttle lever a few times (from minimum to maximum) until the circuit is completely full and pump injector flow is even.

Now carry out test as follows:

- Pump 10 times. Ensure that jet ends each delivery. Leave in minimum position for a few seconds to give the pump time to fill.

– Pump capacity, i.e. the amount of petrol collected in a test tube after 10 pumps, should be 8.5 - 14 cm³.




Petrol jet from pump nozzle should not hit the choke and centring device but emerge as vertically as possible.

ADJUSTMENT OF ENGINE IDLE SPEED AND CO CONTENT ON CAR



Carry out this adjustment after engine has warmed up (i.e. after the radiator fan has cut in for the second time) with the fan off, air filter installed and choke fully in.



PX051P402

Adjust as follows:

- introduce the exhaust gas analyser probe into the exhaust tail pipe;
- fit the revolution counter;
- remove the idle mixture adjustment screw protective cover, if present;
- adjust engine to a speed of 850 ± 50 /min using the main throttle adjustment screw;
- adjust mixture composition with the idle mixture adjustment screw until engine turns smoothly. Check that CO (carbon monoxide) exhaust emissions are between 0.5% - 1.5%;
- adjust the two screws until values are as specified;
- fit a new idle mixture adjustment screw cover of a different colour to the original.

COLD STARTING PROCEDURE

Start the engine without depressing the accelerator pedal.


Pull the clutch fully out (a ratchet device holds it in the required position) and start the engine



The ignition switch is fitted with an anti-repeat device. If the engine fails to start, the key must therefore be returned to the STOP position before attempting to start the car again.

a) With outside temperature above 20°C

- 20 seconds after starting, lower the choke lever by about 1/3 of its travel;
- after 30-40 seconds, lower the choke lever by about 2/3 of its travel;
- put choke fully back in after about 2 minutes.




PX055P402

b) With outside temperature below 20°C

- 30 seconds after starting, gradually lower the choke lever at a rate depending on outdoor temperature until device is fully in.

10.

FUEL FEED SYSTEM





FEED PUMP





Checking feed pump, spacer and gaskets

NOTE Although petrol leakage may be corrected by tightening outer pump housing screws, no other adjustments may be carried out and pump replacement is therefore necessary.




Installation of gaskets, spacer, rod and feed pump on engine



Checking feed pump delivery pressure (engine on car)


Feed pressure must be between 0.107-0.200 bar (0.10-0.21 kg/cm²) at an engine speed of 4000 rpm.

NOTE If pressure is higher than specified, replace gasket between pump and spacer with a thicker version. If pressure is lower than specified, fit a thinner gasket.




10.



CUTAWAY VIEW OF ENGINE





PX058P401

**2,1 daNm**

Installation and torque tightening of coolant pump impeller on accessory shaft




Installation of gasket and coolant pump cover on oil sump



Installation of gasket and thermostat on coolant pump cover

10.

COOLING SYSTEM DIAGRAM



1. Coolant radiator
2. Coolant expansion tank
3. Coolant delivery line from radiator to pump
4. Coolant delivery line from expansion tank to pump
5. Coolant recycle line from cylinder head to pump
6. Coolant delivery line from cylinder head to coolant radiator
7. Coolant outlet from pump to engine block
8. Coolant intake from cylinder head
9. Coolant delivery line from cylinder head connector to intake manifold
10. Coolant delivery line from cylinder head connector to car interior radiator-heater
11. Car interior radiator-heater
12. Coolant delivery line from car interior radiator-heater to thermostat
13. Coolant delivery line from coolant radiator to expansion tank
14. Thermostat with by-pass for coolant mixing
15. Cylinder head connection

Delivery circuit

Return circuit


BY-PASS THERMOSTAT OPERATING DIAGRAM

Engine cold

The cooling system is pump driven with an built-in expansion tank and vane impeller pump

When the coolant is at a temperature below 85°- 89°C, the thermostat is completely closed from the radiator end. The pump therefore takes coolant from the cylinder head (via the recycle line) and directs it to the engine block (through ducts in the oil sump), where it is heated. Under these conditions the coolant circulates only from the cylinder head to the engine block.

Closed position




PX061P401 PX061P402

Engine hot

When the coolant temperature exceeds 89°C the thermostat starts to open, including the part connected to the radiator. The pump can therefore suck up coolant from the bottom of the radiator and the expansion tank.

This therefore causes the coolant to circulate directly from the cylinder head to the top of the radiator. The relatively cooler coolant from the bottom of the radiator, radiator tank and expansion tank is drawn up by the impeller pump. The system therefore exerts a maximum cooling effect.

Fully open position




PX061P403 PX061P404




The two-stage electric coolant fan then cuts in at temperatures of 96°- 100°C and 101°- 105°C (measured at the bottom of the radiator), to trigger the cooling action of the system.

Cleaning and descaling radiator

Follow instructions supplied with descaler for washing outside and descaling inside.




1. Radiator
2. Thermostat
3. Coolant expansion tank
4. Radiator fan thermostatic switch
5. Three-way connector on cylinder head



PX062P401

Checking radiator cap discharge valve

Should open at a pressure of 0.98 bar (1 kg/cm²).



PX062P402


Coolant system pressure leak test

Pump to obtain a pressure of 0.98 bar (1 kg/cm²) and check for coolant leakage.



Installation of ignition breaker and timing adjustment


Position crankshaft so that pulley notch is aligned with notch on plate (indicating 10° advance). Then connect ignition breaker to engine, ensuring that contacts or platinum plated points are starting to open. Now tighten the retaining bolt.




PX063P401



Install gasket and coolant outlet (complete with temperature sender unit) on cylinder head.




PX063P402




PX063P403



Install exhaust manifold




PX063P404




Install fuel delivery line (1) from pump to carburettor

Install coolant delivery line (2) from cylinder head outlet to intake manifold



Installation of alternator and adjustment of drive belt



ADJUSTMENT OF ALTERNATOR DRIVE BELT TENSION

Install new belt at a tension of 40 - 50 kg, measured using tool 1895760000 or tool 1895762000.

Run engine at 3000 rpm for 15 minutes. Leave the engine to cool for 15 minutes. Adjust belt tension to 40-50 kg.


Periodic checking of tension

Check tension with tool 1895760000 or tool 1895762000. If load is ≤ 15 kg, adjust tension to 25 - 35 kg.




Tension must be checked with engine cold.

Installation of vacuum advance corrector and installation of low oil pressure switch



Installation of oil dipstick




Checking oil pressure at 100°C

Lubrication pressure must be between 2.94 - 4.8 bar.



Install threaded connector in place of low oil pressure warning switch



10.A

1840051000	Cylinder head extractor	1870414000	Beam for support of engine in car during removal and attachment of rear beam
1840206000	Percussion extractor (use with special parts)	1890310000	Smoothing tool ($\varnothing 8$ mm) for engine valve guide holes
1840207812	Part ($\varnothing 12$ -14 mm) for crankshaft bush removal	1890338001	Borer ($\varnothing 22.05$ mm) for oversize tappet guide holes
1840207813	Part ($\varnothing 14$ -18 mm) for coolant pump packing box and oil seal removal (use with 1840206000)	1890338002	Borer ($\varnothing 22.10$ mm) for oversize tappet guide holes
1850089000	Rocker shaft support retaining bolt lock bush	1895362000	Tester for coolant system leaks
1850117000	Valve rocker adjustment screw wrench	1895683000	Device for checking engine cylinder compression (scale 4.05-18.2 bar)
1860158000	Support for cylinder head during valve assembly and disassembly	1895683002	Cards for device 1895683000
1860161000	Flywheel clamp (bench)	1895762000	Torque wrench for checking rubber belts
1860162000	Pressure gauge with connector for oil pressure check (scale 0-9.81 bar)	1895868000	Device for valve leak tests
1860183000	Pliers ($\varnothing 75$ -110 mm) for piston ring removal and installation		
1860212000	Driver for crankpin assembly and disassembly		
1860213000	Driver ($\varnothing 20$ mm) for crankpin bush assembly and disassembly		
1860395000	Driver for valve guide removal and installation		
1860449000	Pair of threaded journals for flywheel operation during timing check		
1860470000	Stand for cylinder head during overhaul		
1860490000	Clamp for leak testing of valves		
	1895868000 (use with 1860470000)		
1860592000	Multi-purpose hook for engine-gearbox unit lifting and transport		
1860605000	Collar ($\varnothing 60$ -125 mm) for insertion of normal and oversize pistons in cylinders		
1860644000	Valve removal and installation tool		
1860691000	Coupler for fitting oil seal to valve guide		
1861001034	Bracket for fixing flywheel end of engine to rotary stand		
	1861000000		
1861001036	Parts for securing engine to rotary stand 1861000000 (use with 1861001034)		
1865501000	Tool for testing carburettor accelerator pump flow		
1870152000	Driver for installation of coolant pump packing box		

PART	Thread	Tightening torques
		daNm

ENGINE

Camshaft and flywheel end bearing support retaining screw	M 8	2.7
Cap nut retaining cylinder head to engine block	M 10 x 1.25	4.9
Screw retaining cylinder head to engine block	M 8	3
Screw retaining cylinder head to engine block	M 9 x 1.25	4
Nut for con rod bolt	M 8 x 1	3.4
Screw retaining flywheel to crankshaft	M 8	4.4
Screw retaining driven gear to camshaft	M 6	1
Nut retaining rocker support	M 8	2.4
Screw retaining alternator drive pulley	M 24 x 1.5	14.7
Nut retaining alternator driven pulley	M 14 x 1.5	7.5
Spark plug	M 14 x 1.25	2.8
Oil pressure switch	M 14 x 1.5 (cylindrical)	3.2
Self-locking nut for cylinder head cover retaining stud	M 8	0.8
Oil drain plug	M 22 x 1.5	5
Screw retaining oil suction filter to engine sump	M 8	2.1
Screw retaining coolant pump impeller to spindle	M 8	2.1
Screw retaining coolant pump cover to sump	M 6	0.7
Screw retaining thermostat to coolant pump cover	M 8	2.5
Screw retaining sump to engine block	M 6	0.8

10.

PART	Thread	Tightening torques
		daNm

POWER UNIT SUSPENSION

Screw retaining suspension support to body shell	M 8	2.5
Screw retaining beam to gearbox	M 8	2.5
Screw for retaining front power unit bracket	M 10 x 1.25	4.9
Screw for bracket attaching power unit to suspension	M 10 x 1.25	4.9
Nut retaining rubber block to power unit	M 10 x 1.25	4.9

ENGINE EXHAUST


Nut retaining exhaust silencer to manifold	M 8	1.8
Screw retaining exhaust silencer support	M 8	2.4
Screw retaining exhaust silencer to engine	M 8	2.4

REMOVING-REFITTING



P1V001F01

Removing-refitting horn control



P1V001F02

Removing-refitting
steering wheel and horn
control springs


P1V001F03



P1V001F04

Removing-refitting bolts fixing shield to
upper shaft and steering column switch
unit


41.



Removing-refitting nut fixing shield and upper shaft to bodyshell




Removing-refitting steering column switch unit from upper shaft




Removing-refitting electric cable loom seal


The seal can be found on the bulkhead between the passenger compartment and the engine compartment




Disconnect the 3 connectors for the electrical cables which go to the steering column switch unit



Removing-refitting upper shaft and steering column switch unit cover



Steering column switch unit complete with electrical cables and connections



Upper steering shaft and steering column switch unit cover



41.



Removing-refitting nuts fixing upper steering shaft mounting to the bodyshell




Removing bolts with pre-arranged breaking load, using automatic locking pliers and jaws



Removing-refitting lower shaft from steering box pinion.

The arrow shows the nut to be undone in order to remove the lower shaft.



Steering gear

P1V005F01

Dismantling upper steering shaft
from lower shaft at the bench

P1V005F02

Dismantling upper
steering shaft from
mounting at the bench


Before removing the upper shaft and the bushes from the mounting, remove the staking on the lower steering shaft side of the mounting.



P1V005F04




P1V005F03

Refitting upper shaft and bushes on the
mounting

P1V005F05

41.





Checking steering gear components


Check that the clearance between the upper steering shaft and the flexible bushes is not too large and that the shaft is not off centre. Check that the spider clearance for the lower steering shaft universal joints is not too large. If any anomalies whatsoever are found, replace the affected components.

1. Upper steering shaft mounting
2. Flexible mountings
3. Upper steering shaft
4. Lower steering shaft with universal joints

Longitudinal sections of rack and pinion steering box




Steering gear components available as spares



1. Steering wheel
2. Upper steering shaft
3. Upper steering shaft bushes
4. Upper steering shaft mounting
5. Lower steering shaft with universal joints
6. Steering box
7. Side steering rod
8. Steering box mountings
9. Brackets fixing steering box to bodyshell



41.





REMOVING-REFITTING




View of steering box assembly fitted on vehicle



Removing side from steering control lever





Removing-refitting horns



Removing-refitting steering box from bodyshell

The brackets and the rubber mountings have to be removed in order to carry out the removing-refitting procedure







Removing-refitting steering box assembly

The arrow shows the left side of the vehicle where the steering box can be removed from.



Carry out the front wheel toe in each time the steering box is removed-refitted

41.



REMOVING-REFITTING



Removing-refitting rod complete with track rod end

Check that there are no signs of hardening or excess clearance in the track rod end or else it must be replaced.




Removing-refitting protective boot and oil seal

Carefully check that there are no holes or tears in the boot or else it must be replaced.



Before fitting the last boot (pinion side), apply the recommended amount of grease.




Removing-refitting ball joint


There should be no signs of hardening in the ball joint but it should turn freely in all directions without falling under its own weight.



When the refitting has been carried out, stake the edges of the ball joint seat as shown by the arrow.




Steering box components available as spares





1. Rack support flexible bush
2. Rack
3. Worm screw
4. Ball joint
5. Support cover
6. Spring
7. Adjustment shims (available as spares in the following sizes: 0.25-0.30-0.35-0.45 mm)
8. Seal
9. Support
10. Steering box
11. Protective boot and seal

41.



P1V012F01



P1V012F02


Fitting and adjusting rack support

NOTE *The determining of the thickness of the shims should be carried out without the spring and seal fitted.*

The adjustment is carried out using shims placed between the steering box casing and the support cover. The value of the shims to be used is obtained by adding 0.05 - 0.13 mm, corresponding to the clearance between the support and the cover to distance Y. The adjustment shims are available in the following sizes 0.25 - 0.30 - 0.35 0.45 mm.

NOTE *When the steering box has been fitted, the torque required to start the rotation of the pinion should be between 1.3 and 2.1 Nm (13.25 and 21.5 kgcm).*

ADJUSTING FRONT WHEEL TOE IN



P1V012F04

P1V012F03

The adjustment of the front wheel toe in is carried out by loosening the rod lock nut and tightening or loosening the steering rod until the correct toe in is obtained without altering the position of the steering wheel spokes.

1847044000 Tool for removing steering rod ball joints
1874247000 Tool for fitting rack rod bush
1895697000 Dynamometer (0-4.90 Nm) for measuring steering box bearings rolling torque
1895697009 Tool for checking steering box bearings rolling torque (to be used with 1895697000)


Tightening torques

DESCRIPTION	Thread size	Tightening torque
		daNm


Steering wheel to steering shaft fixing, nut	M 16 x 1,5	4,9
Universal joint fork to steering shaft fixing, nut	M 8	2,6
Upper steering shaft rear mounting fixing, nut	M 8	1,5
Upper steering shaft mounting fixing, nut	M 8	1,5
Ball joint to steering control levers fixing, nut	M 10 x 1,25	3,4
Steering box fixing, bolt	M 8	2,5
Ball joint to side steering rod fixing, nut	M 14 x 1	4,9

REMOVING-REFITTING


In order to remove and refit the front suspension from the vehicle, after positioning the vehicle on a lift and removing the front wheels, proceed as illustrated below.




Front suspension assembly on vehicle



Removing front wheel hub cap



Removing side steering rod from lever on steering knuckle




Removing flexible brake pipe from union, on the bodyshell

44.




Removing nut fixing shock absorber to bodyshell



Removing leaf spring from steering knuckle damper



In order to remove the fixing bolt, the end of the leaf spring (near the flexible bush) has to be compressed using a hydraulic jack.



Removing track control arm pin from the bodyshell




Whilst removing the front suspension make a note of the number of shims (shown by the arrow) between the bodyshell and the track control arm pin in order to avoid altering the wheel angles (camber and caster) when refitting.




Front suspension assembly removed from the vehicle



In order to remove the complete suspension, carry out the same operations as described previously, only this time on the other side.



P1V003G01




P1V003G02

DISMANTLING-REASSEMBLING




Removing staking on nut retaining front wheel hub



P1V003G03




Removing front wheel hub retaining nut



P1V003G04


44.



P1V004G01




Removing brake drum



P1V004G02




Removing wheel hub from steering knuckle




P1V004G03




Removing brake back plate assembly from steering knuckle



Removing track control arm from steering knuckle damper



Removing shock absorber from steering knuckle damper



Shock absorber check

If any anomalies which are attributable to the shock absorber are found, it must be replaced in one piece.


Suspension and wheels

Front suspension

126 BIS


44.

FRONT SUSPENSION COMPONENTS, AVAILABLE AS SPARES



1. Nut fixing pin to track control arm
2. Cap
3. Flexible bush
4. Spacer
5. Pin for track control arm
6. Plate for adjusting camber and caster
7. Spacer
8. Nut fixing track control arm pin to bodyshell
9. Leaf spring
10. Track control arm
11. Wahser
12. Upper flexible bush
13. Lower cap
14. Lower flexible bush
15. Nut with washer fixing shock absorber to damper
16. Nut for bolt fixing leaf spring to damper
17. Damper for steering knuckle pin
18. Plug
19. Bushes for steering knuckle pin
20. Bolt fixing leaf spring to damper
21. Nut for bolt fixing track control arm to damper
22. Damper flexible bush
23. Bolt fixing track control arm to damper
24. Hydraulic shock absorber
25. Lower flexible bush
26. Upper flexible bush
27. Upper cap
28. Nut with washer fixing upper hydraulic shock absorber to bodyshell


STEERING KNUCKLE COMPONENTS




1. Flexible pin retaining pin to steering knuckle
2. Steering knuckle damper
3. Steering knuckle pin
4. Circlip with thrust ring
5. Steering knuckle
6. Seal
7. Circlip
8. Internal roller bearing
9. External roller bearing
10. Safety plate
11. Nut for steering knuckle for adjusting axial clearance
12. Lower circlip
13. Lower shim for adjusting steering knuckle end float
14. Grease cup

The lower shims are available as spares in the following sizes: 2.50 - 2.52 - 2.54 - 2.56 - 2.58 - 2.60 - 2.62 - 2.64 - 2.66 - 2.68 - 2.70 - 2.72 - 2.74 - 2.76 - 2.78 - 2.80 - 2.82 mm.


STEERING KNUCKLE




Removing - refitting
steering knuckle damper
flexible bush on the press



Removing flexible pin retaining pin to
steering knuckle



Removing steering knuckle pin from
damper


44.

The steering knuckle should not show any signs of cracks, distortion or wear or else it must be replaced.



Examine the condition of the two circlips, upper and lower and the lower thrust washer; they should not be worn; if necessary, replace them. When refitting, there should not be a large clearance between the steering knuckle and the damper once the two circlips, upper and lower and the lower thrust washer have been fitted.



If this is not the case, fit the appropriate size lower thrust washer until the situation has been rectified.




STEERING KNUCKLE DAMPER




The steering knuckle damper should not show signs of distortion, cracks or wear or else it has to be replaced.



Removing-refitting bushes on steering knuckle damper.





Reaming steering knuckle bushes on damper
(to roughen)




Reaming steering knuckle bushes on damper
(to finish)

TRACK CONTROL ARMS





Removing - refitting nuts fixing pin to track control arm




Removing flexible bushes from track control arm



44.




Fitting flexible bushes and pin for track control arm



WHEEL HUB


Removing - refitting wheel hub seal

The operations of removing and refitting the seal are carried out using ordinary methods.



Removing external roller bearing outer race (shown by arrow) from wheel hub

Removing circlip (1) and outer ring (2) for internal conical roller bearing from wheel hub




P1V011G01




P1V011G02


Check that there are no grooves or signs of wear on the wheel hub bearing seats or else the hub has to be replaced.




P1V011G03



P1V011G04




Fitting outer race for external conical roller bearing on wheel hub




Fitting outer race for internal conical roller bearing on wheel hub

44.



0,7 daNm

NOTE In order to refit the front suspension, simply reverse the order of the operations carried out for its removal.




FRONT WHEEL HUB ADJUSTMENT

In order to adjust the front wheel hub roller bearings end float, the bearing fixing nut must be tightened to a torque of 0.7 daNm and then loosened through 30° (as illustrated in the diagram below).


Under these circumstances the end float should be 0.025 - 0.100 mm.

Diagram showing front wheel hub roller bearing end float adjustment

- A. Corner of nut after tightening to a torque of 0.7 daNm.
- B. Reference mark on wah ser for loosening nut by 30°.




Staking nut fixing front wheel hub





Fitting front wheel hub cover

NOTE Before fitting, smear TUTELA MR3 grease along the edges of the hub cap

REMOVING-REFITTING
LEAF SPRING


Front suspension assembly fitted on vehicle

P1V009F01




P1V013G01

P1V013G02



P1V013G03



P1V013G04

Remove the flexible mountings for fixing the leaf spring to the bodyshell

The leaf spring eyelet has to be supported by the hydraulic jack before removing the flexible mountings.


Suspension and wheels

Front suspension


126 BIS

44.

LEAF SPRING COMPONENTS



 The individual leaf springs, including the main one, are available as spares, however, if necessary, replace the complete leaf spring.




Checking leaf spring

Make sure that the leaf springs are not cracked, broken or distorted in such a way that would adversely affect their operation.

NOTE The flexible bush should be replaced when traces of sliding or wear are noticed.


Removing - refitting flexible bush on leaf spring

CROSS SECTION OF FRONT SUSPENSION ASSEMBLY




44.

CROSS SECTION OF LEFT REAR WHEEL AND DIFFERENTIAL DRIVE SHAFT




REMOVING-REFITTING


In order to remove and refit the rear suspension, position the vehicle on a lift, remove the rear wheels and then proceed as illustrated below:





- disconnect the brake fluid pipe from the union;




- disconnect the handbrake rod from the control lever;




- removing bolts fixing track control front mounting to bodyshell;




- removing bolts fixing drive shaft sleeve to flexible joint;




- removing rear bolt fixing track control arm to bodyshell. Make a note of the number of shims at the sides of the flexible bush and of their position.





- removing nut fixing hub to track control arm;



44.





Using the hydraulic jack, compress the shock absorber and the coil spring to facilitate their removal.



Removing - refitting nut fixing shock absorber to bodyshell and removing - refitting shock absorber

In order to reach the nut fixing the shock absorber to the bodyshell the rear seat has to be folded over and the rear parcel shelf cover raised.



Lower the hydraulic jack and remove the right rear suspension assembly, complete with brake drum.



NOTE In order to remove-refit the left rear suspension simply repeat the operations carried out for removing the right rear suspension.

In order to refit the rear suspension simply reverse the order of the operations carried out for its removal, except for the two operations described below:


- tighten, but not fully, the bolts (shown by the arrows) fixing the mounting to the bodyshell; these bolts are tightened to a torque of 4.7 daNm only after the toe in has been adjusted;

- insert the inner end of the track control arm in the bodyshell mounting; refit the adjustment shims between the flexible bush and the mounting; using guide pin 1874057000, align the shims and the flexible bush; remove the tool, replacing it with the fixing bolt; tighten the nut to a torque of 7.8 daNm, after adjusting the toe in.

Centering flexible bush and shims on track control arm




44.




DISMANTLING-REASSEMBLING




Removing stud and bolt fixing brake drum to hub



Removing brake drum




Removing wheel shaft




Wheel shaft

The wheel shaft should not show any signs of cracks, distortion or wear on the surfaces where the bushes are fitted or, else it has been replaced.


Removing brake back plate and wheel hub




P1V021G01



P1V021G03



P1V021G02




P1V021G04

Removing track control arm mounting

Check that the track control arm mounting is not distorted or else it must be replaced.


TRACK CONTROL ARM




P1V021G05

Check that the track control arm is not distorted or else it must be replaced.
Check that the flexible bushes are not worn or else they have to be replaced.


44.



Removing-refitting fleixble bush from lower section of track control arm



Removing-refitting flexible bush from front section of track control arm




P1V022G03

Coil spring

Make sure that there are no cracks or distortions which would adversely affect its operation.

NOTE *The coil springs are subdivided and marked with a stripe of either yellow or green paint. Springs of the same category must be fitted.*




P1V022G04

Shock absorber


If any faults are found in the shock absorber, it must be replaced in one piece.

REAR SUSPENSION COMPONENTS AVAILABLE AS SPARES


1. Bolt fixing track control arm to mounting
2. Adjustment shims
3. Track control arm mounting
4. Bolt fixing mounting to bodyshell
5. Flexible mounting for track control arm
6. Nut with washer for bolt fixing track control arm to mounting
7. Track control arm
8. Rubber seal for coil spring
9. Rubber seal housing
10. Coil spring
11. Rubber buffer



12. Nut for fixing hydraulic shock absorber to bodyshell
13. Cap
14. Upper flexible bushes
15. Bolt fixing hydraulic shock absorber to track control arm
16. Bush fixing hydraulic shock absorber to track control arm
17. Lower flexible bush
18. Nut with washer for bolt fixing hydraulic shock absorber to track control arm
19. Washer
20. Hydraulic shock absorber
21. Track control arm
22. Lower flexible bush



44.






WHEEL HUB

Wheel hub components

1. Seal on hub
2. Spacer
3. Circlips
4. Roller bearings
5. Flexible spacer
6. Wheel shaft
7. Wheel hub
8. Flexible joint
9. Nut fixing flexible joint and hub to wheel shaft



The presence of the flexible spacer between the two bearings ensures constant adjustment and reduces the axial variations during operation.



FIAT
(A)



Removing - refitting seal on hub

The operations of removing - refitting are carried out using ordinary methods.



Removing roller bearing outer race

The removal is carried out using an ordinary drift.



The flexible spacer (5) and the nut (9) fixing the spacer and the hub to the wheel shaft (6) should always be replaced each time they are removed.




FIAT
(A)



Fitting internal and external roller bearing outer races on rear wheel hub



When refitting the bearings, they should be generously greased using TUTELA MR3 grease.




P1V025G01

Flexible joint

The flexible joint should not have undergone any damage which would adversely affect the join between the metal and rubber sections.


Longitudinal section of left rear wheel hub and brake drum

1. Nut fixing flexible joint and hub to wheel shaft
2. Flexible joint
3. Wheel shaft
4. Wheel hub bearings
5. Wheel hub
6. Brake drum



P1V025G03

REAR WHEEL HUB BEARING PRE-LOADING







1895697000

1895697003

44.

FRONT WHEEL GEOMETRY



TOE IN

$$a - b = 2 \div 6 \text{ mm}$$

CAMBER


$$\alpha = 1^\circ 40' \pm 30'$$

CASTER

$$\varepsilon = 9^\circ \pm 1^\circ$$

Diagrams for checking and adjusting camber, toe in and caster angles for steering knuckles

1. Pin and nut for join between track control arm and steering knuckle
2. Nuts fixing pin to track control arms
3. Pin and nut for join between leaf spring and steering knuckle
- 4-5. Bolts with nut for fixing track control arm to bodyshell
6. Nuts fixing leaf spring mounting to bodyshell
7. Leaf spring flexible mounting
8. Shims for adjusting camber and caster angles
9. Wheel centre





The wheel geometry should be checked after subjecting the components which affect it to the following checks:

- check tyre inflation pressure;
- check eccentricity and squareness of wheel rims which should not exceed 3 mm;
- check wheel bearing end float (0.025 - 0.100 mm);
- check clearance between steering knuckle damper and pin;
- check steering track rod end clearance.

If the results of the wheel geometry check differ from the figures given, proceed as follows:


- for the toe in, act on the steering box rods after loosening the fixing nuts (see section 41, page 12);
- for the adjustment of the camber and caster angles, follow the instructions given below.

ADJUSTING FRONT WHEEL CAMBER ANGLE



In order to adjust the camber angle, disconnect the shock absorber (1) from the bodyshell, remove the track control arm (5) and alter the number of adjustment shims (2) placed between the track control arm (5) pin (4) and the bodyshell; remove an equal number of shims from both bolts (3) to decrease the camber angle or alternatively add an equal number of shims to both bolts (3) to increase it.

ADJUSTING DAMPER CASTER ANGLE



In order to adjust the damper caster angle, disconnect the shock absorber from the bodyshell, remove the track control arm (5) and alter the number of adjustment shims (2) placed between the track control arm and the bodyshell;

- in order to increase the caster angle, move shims (2) from the rear bolt (1) to the front bolt (3);
- in order to decrease the caster angle, on the other hand, move shims from the front bolt (3) to the rear bolt (1).

44.

REAR WHEEL GEOMETRY

The wheel geometry should be checked after the following checks have been carried out:

- tyre inflation pressure;
- the eccentricity and squareness of the wheel rims should not exceed 3 mm;
- check wheel bearing end float.

Diagrams for checking and adjusting rear wheel toe in and camber angles

TOE IN

$$a - b = 1,5 \div 5,5 \text{ mm}$$

CAMBER

(not adjustable)

$$\alpha = 3^\circ \pm 30'$$






Diagram for checking toe in

1. Mounting for fixing track control arm to bodyshell
2. Slots in mounting for adjusting rear wheel toe in
3. Pin and nut fixing track control arm to bodyshell
4. Pin and nut fixing track control arm to mounting
0. Wheel shaft centre



ADJUSTING TOE IN



The adjustment of the rear wheel toe in is carried out by moving the bearing (2) on the fixing bolts.

This movement is made possible by the slots (1) in the actual bearing.

If the toe in needs considerable adjustment, also move the adjustment shims (3) for the track control arm rear mounting from one end of the flexible bush to the other.



WHEEL ALIGNMENT

Checking the alignment of the rear wheels with the front wheels should be carried out to check that front wheel torque and the rear wheel torque are symmetrical in relation to the vehicle centre line axis. The degree of error found should be divided equally between the two rear wheels in order to alter the track.

The adjustment of the rear wheel alignment with the front wheels is carried out by moving an equal number of adjustment shims from one side of the track control arm to bodyshell mounting flexible bushes to the other.

The same operation should be carried out in reverse for the track control arm mountins on the other side.

44.

1847014000	Percussion extractor for wheel hub covers	1874369000	Drift for fitting rear wheel hub bearing outer race (to be used with tool 1870007000)
1847015000	Tool for removing front wheel hubs	1890316001	Reamer for roughening steering knuckle bushes
1847017004	Plate for removing wheel hubs (to be used with tool 1847017001)	1890316002	Reamer for finishing steering knuckle bushes
1857020000	Spanner for retaining rear shock absorber stem whilst tightening and loosening fixing nut	1895697003	Tool for measuring rear wheel hub bearing rolling torque (to be used with tool 1895697000)
1857030000	Spanner for retaining front shock absorber stem whilst loosening and tightening fixing nut		
1874016000	Drift for removing - refitting bushes on steering knuckle		
1874053000	Drift for removing - refitting flexible bushes on rear suspension arm		
1874056000	Drift for removing - refitting flexible bushes on steering knuckle and leaf spring		
1874057000	Guide pin for fitting shims on rear suspension track control arm		
1874088000	Drift for fitting wheel hub covers		
1874140002	Pair of tools for staking front wheel hub nuts (to be used with tool 1874140001)		
1874366000	Drift for fitting front wheel hub outer bearing outer race (to be used with tool 1870007000)		
1874367000	Tool for removing flexible bushes from front suspension track control arm (on the press)		

DESCRIPTION	Thread size	Tightening torque
		daNm

FRONT SUSPENSION

Front wheel fixing bolt/nut	M 12 x 1,25	6,9
Leaf spring to steering knuckle fixing, nut with polyammide ring	M 10 x 1,25	3,9
Track control arm to pin fixing, nut	M 14 x 1,5	4,9
Track control arm to pin fixing, nut with polyammide ring	M 14 x 1,5	5,9
Front suspension rubber buffer fixing, nut	M 8	1,5
Leaf spring flexible mounting, nut with polyammide ring	M 10 x 1,25	4,9
Track control arm pin to bodywork fixing, nut with polyammide ring	M 10 x 1,25	4,9
Pin fixing track control arm to steering knuckle fixing, nut with polyammide ring	M 10 x 1,25	5,7
Front suspension upper and lower shock absorber fixing, nut	M 8	2
Left steering knuckle, nut to be staked	M 14 x 1,5	(see page 12)

REAR SUSPENSION


Rear wheel fixing nut/bolt	M 12 x 1,5	6,9
Rear suspension rubber buffer fixing, nut	M 8	1,5
Rear suspension front arm mounting to under body fixing, bolt	M 10 x 1,25	4,7
Rear suspension attachment pin, nut with polyammide ring (low type)	M 12 x 1,25	7,8
Rear suspension upper and lower shock absorber fixing, nut with polyammide ring	M 12 x 1,25	2,9
Rear wheel brake back plate and hub to track control arm fixing, nut	M 10 x 1,25	5,6

00.10



SPECIFICATIONS

Type	126 A2.000		
	Cycle OTTO 4 stroke		
	Number of cylinders 2 in line		
	Bore	mm	80
	Stroke	mm	70
	Capacity	cc	703
	Compression ratio		8.6 ± 0.15
	Power output (EEC)	kW (hp)	18.5 (26)
		rpm	4500
	Torque rating (EEC)	daNm (kgm)	4.7 (5)
		rpm	2000



Power output curves measured by the EEC method


The power curve illustrated can be obtained when the engine is overhauled and run in, without fan, with exhaust silencer and air cleaner fitted and at sea level.

Bench tests on overhauled engines

When bench testing overhauled engines, they should not be run at maximum speed but in accordance with the data specified in the table below; running in should be completed in the car.

Test speed (rpm)	Time in minutes	Brake load
800 - 1000	10'	no load
1500	10'	no load
2000	10'	no load

00.10







DIMENSIONS AND TOLERANCES


		mm
Camshaft journal or bush locations		
	timing gear side Ø ₁	22.015 - 22.036
	flywheel side Ø ₂	43.020 - 43.045
Tappet locations		
	Ø	22.021 - 22.030
1		
	Cylinder liner location Ø	85.970 - 86.000
2		
	Cylinder liner Ø ₁ { A B C Ø ₂	80.000 - 80.010 80.010 - 80.020 80.020 - 80.030
2-1		Ø ₁ FLAT > 0.030 - 0.060

(*) Replacement block is supplied complete with cylinder liners

DIMENSIONS AND TOLERANCES

			mm
3		X	14.5
		A	79.950 - 79.960
		B	79.960 - 79.970
		C	79.970 - 79.980
Piston		\emptyset FIAT >	0.4
			± 5 g
3-1		Piston - Cylinder bore	0.040 - 0.060
3		Gudgeon pin location	\emptyset 19.996 - 20.000
4		Gudgeon pin	\emptyset 19.990 - 19.994
		\emptyset FIAT >	-
4-3		Gudgeon pin - Pin location	0.002 - 0.010
3		 1	1.535 - 1.555
		 2	2.030 - 2.050
		 3	3.967 - 3.987
5		 1	1.478 - 1.490
		 2	1.978 - 1.990
		 3	3.925 - 3.937
Piston rings		\emptyset FIAT >	0.4
5-3		 1	0.045 - 0.077
		 2	0.040 - 0.072
		 3	0.030 - 0.062
5-2		 1	0.30 - 0.45
		 2	0.20 - 0.35
		 3	0.20 - 0.35

00.10



DIMENSIONS AND TOLERANCES

			mm
6		Small end bush or gudgeon pin location	\varnothing_1 21.939 - 21.972
6		Big end bearing location	\varnothing_2 47.130 - 47.142
7		Small end bush	\varnothing_1 22.000 - 22.006
7			\varnothing_2
7-6		Small end bush Bush location	0.028 - 0.091
4-7		Gudgeon pin Small end bush	0.006 - 0.016
8		Main journals	\varnothing_1 1 53.970 - 53.980
8			\varnothing_1 2 53.980 - 53.990
8		Crankpins	\varnothing_2 44.000 - 44.020
9		Big end bearings	\varnothing 1 54.010 - 54.025
9			\varnothing 2 54.020 - 54.035
9-8		Big end bearings - Journals	\varnothing_1
9-8			0.2 - 0.4 - 0.6 - 0.8 - 1.00
9-8			0.030 - 0.055

(*) Fully machined and complete with caps

DIMENSIONS AND TOLERANCES



		mm
10		1.534 - 1.543
10-8		0.254 - 0.508
10-8		0.024 - 0.074


Diagram of piston/connecting rod assembly showing orientation in engine

1. Camshaft
2. Area where the number of the connecting rod's matching cylinder bore is stamped

The arrow indicates the direction of rotation of the engine viewed from the timing gear side.






00.10



DIMENSIONS AND TOLERANCES

			mm
12	Valve guide bore in cylinder head	\emptyset	13.950 - 13.977
12	Valve seat	α	45° ± 5'
12		L	approx. 2
13	Valve guide	\emptyset_1	8.022 - 8.040
13		\emptyset_2	14.040 - 14.058
13-12	Valve guide Bore in cylinder head	\emptyset_2	0.05 - 0.10 - 0.25
13-12			0.063 - 0.108
14	Valves	\emptyset_1	7.974 - 7.992
14		\emptyset_2	32
14		α	45° 30' ± 5'
14-13	Valve - Valve guide	\emptyset_1	7.974 - 7.992
14-13		\emptyset_2	27
14-13		α	45° 30' ± 5'
14-13			0.030 - 0.066

DIMENSIONS AND TOLERANCES


		mm
15		P ₁ 27.7 - 31.2 daN H ₁ 39 P ₂ 61.0 - 66.7 daN H ₂ 29.3
17		Ø ₁ 21.979 - 22.000 Ø ₂ 42.975 - 43.000
17-1		0.015 - 0.057 0.020 - 0.070
19		Ø 21.978 - 21.996 0.05 - 0.10
19-1		Ø 0.025 - 0.052
22		Ø 18.016 - 18.043
25		Ø 18.005 - 18.023
26		Ø 17.988 - 18.000
26-22		Ø 0.016 - 0.055
26-25		Ø 0.005 - 0.035

Technical data

Engine: cylinder head and timing gear

126 BIS


00.10



DIMENSIONS AND TOLERANCES


		mm
for checking timing		0.39
operating		0.39
		0.15 ± 0.05
		0.15 ± 0.05
Volume of combustion chamber in cylinder head	cc	(average value) 39.15

TIMING DIAGRAM



VALVE TIMING





A	Inlet		opens before TDC	25°
B			closes after BDC	51°
C	Exhaust		opens before BDC	64°
D			closes after TDC	12°




DIMENSIONS AND TOLERANCES

			mm
24		\varnothing_1	15.989 - 16.000
		\varnothing_2	11.901 - 11.913
	Ancillary components shaft journals	\varnothing_3	15.970 - 15.985
1		on oil sump \varnothing_1	16.016 - 16.034
		on oil inlet suction rose \varnothing_2	11.939 - 11.956
	Ancillary components shaft bearings	on block \varnothing_3	16.016 - 16.037
24-1	Ancillary components shaft journals - Location in sump		0.016 - 0.045
	Ancillary components shaft journals - Location in oil inlet suction rose		0.026 - 0.055
	Ancillary components shaft bearings - Location in block		0.031 - 0.067

00.10

DIMENSIONS AND TOLERANCES		mm
Engine lubrication system		forced circulation by a rotor pump, with full-flow centrifugal oil filter
Oil pump type		rotor
Pump drive		ancillary components shaft
Oil pressure relief valve		incorporated in oil pump
Full-flow filter		centrifugal
Oil pressure gauge sender unit		electric
	between gear periphery and pump body	 0.125 - 0.189
	between gear top and cover	 0.045 - 0.120
	between driving gear and driven gear	 0.025 - 0.100
	Operating pressure at 100°C	2.94 - 4.8 bar
	P ₁	2.35 - 2.45 daN
	H ₁	36
	P ₂	4.29 - 4.54 daN
Oil relief valve spring	H ₂	29

COOLING SYSTEM

Cooling system	coolant circulation by a centrifugal pump, with radiator, two-speed fan controlled by thermal switch and expansion tank "Controlled by-pass" thermostat located on the oil sump near the centrifugal pump. Secondary circuit for coolant recirculation, comprising radiator/car interior heater				
Water pump drive	ancillary components shaft				
 Fan thermal switch	1st speed	2nd speed			
	96° - 100°C	101° - 105°C			
 Water thermostat	94° - 90°C	95° - 90°C			
	starts opening	85° - 89°C			
	fully open	100°C			
 Clearance between pump impeller and pump housing in sump	valve stroke	≥ 7.5 mm			
		0.191 - 0.755 mm			
Leak test pressure	0.98 bar				
Expansion tank cap relief valve test pressure	0.98 bar				

FUEL SYSTEM

Pump	mechanical diaphragm	
Capacity	45 litres/h	
 at 4000 rpm	 crankshaft	> 0.2 bar
Minimum pressure		

CHECKING IDLE SPEED AND CARBON MONOXIDE EMISSION

Engine rotation speed	850 ± 50 rpm
CO emission on idle	1 ± 0.5%

Technical data

Engine: fuel system

126 BIS



00.10




WEBER
30 DGF 3/150

CARBURETTOR










		Stage 1	Stage 2
Venturis	mm	18	19
Auxiliary venturi	mm	2.5	2.5
Main jet	mm	0.90	0.90
Air bleed jet	mm	1.85	1.95
Emulsion tube		F 60	F 74
Slow running jet	mm	0.47	0.45
Air idle jet	mm	1.40	0.90
Pump jet	mm	0.40	—
Pump discharge orifice	mm	0.40	—
Power fuel jet	mm	—	—
Power air jet	mm	—	0.45
Power mixture jet	mm	—	1.50
Fuel inlet needle valve	mm	1.50	
Fuel recirculation jet	mm	—	—
Idle mixture adjustment jet	mm	1.30	—
Pull-down vacuum bush	mm	—	—
Idle mixture bush	mm	1.10	—
Progression holes	1st orifice	mm	1.00
	2nd orifice	mm	1.05
	3rd orifice	mm	1.10
	4th orifice	mm	1.00
Float level with gasket	mm	9.5 - 10.5	
Float stroke	mm	—	
Pump ejection (10 deliveries)	cc	8.5 - 14	
Stage 1 partial aperture	mm	4.45 - 4.95	
Stage 1/Stage 2 full aperture	mm	13.5 - 14.5	
Fast idle	mm	0.40 - 0.45	
Choke valve gap	minimum gap	mm	3.5 - 4
	maximum gap	mm	—

		mm
Type		
Engagement/disengagement mechanism		
Diaphragm spring load		185 daN
Driven plate		\varnothing_1 160
		\varnothing_2 112
Clutch pedal position		approx. 20 mm below level of brake pedal
Clutch pedal free travel		approx. 15 mm
Clutch operation		mechanical








00.21-27

GEARBOX


		
		
Synchronizers		
		
Gears		
		3.250
		2.067
Gear ratio		1.300
		0.872
		4.024

DIFFERENTIAL


	mm
 Crown wheel to pinion ratio	9/39 (4.333)
 Ratio at the wheels	 14.083 8.957 5.633 3.779 17.437
 Differential carrier bearings	 tapered roller bearings
 Bearing preload adjustment	 preload shims
 Bearing preload	127 - 147 Ncm (13 - 15 kgcm)
 Backlash between pinion and crown-wheel	0.08 - 0.13
 Pinion position adjustment	 shims
 Fiat Replacement shim thickness	0.10 - 0.15
 Side/pinion gear clearance adjustment	 shims
 Fiat Replacement shim thickness	0.7 - 0.8 - 0.9 - 1.0 - 1.1 - 1.2 - 1.3




00.33

FRONT BRAKES

		mm
	∅ Drum	∅ { 185.24 - 185.53
		186.33
		186.83
	Shoes t < permissible	1.5
	Wheel cylinders ∅	23.80 (15/16")
	Master cylinder (pump) ∅	19.05 (3/4")

REAR BRAKES

		mm
	∅ Drum	∅ { 185.24 - 185.53
		186.33
		186.83
	Shoes t < permissible	1.5
	Wheel cylinders ∅	19.05 (3/4")






Type		rack and pinion
Ratio	 	approx. 3.4 turns
		130 ± 1.5 mm
Minimum turning circle		8.35 m
Steering angle		outer wheel α_1 inner wheel α_2
Steering column		with 2 universal joints

WHEELS

	Tyres	type	135/70 R 13"
	front	{ medium load	1.5 bar
		{ full load	1.7 bar
	rear	{ medium load	2 bar
		{ full load	2.5 bar
	Rim	type	pressed steel 4 x 13" H2

WHEEL GEOMETRY




	camber		1°40' ± 30'
	caster		9° ± 1'
Front suspension	toe-in		2 - 6 mm
	camber (**)		3° ± 30'
Rear suspension	toe-in		1.5 - 5.5 mm

(*) Tyres inflated to the required pressure and vehicle in running order

(**) Non-adjustable angles

Front suspension independent with upper semi-trailing links and hydraulic telescopic shock absorbers. Transversal leaf spring also acting as anti-roll bar.

LEAF SPRING



P1V031A01

Position		Load P daN	Deflection mm	Yield from position 1	Spring rate mm/100 daN
1	Start of spring rate test	120	—	—	62 - 68
2	Reference load	147	20 ± 3	17 ± 2	
3	End of spring rate test	170	—	31 ± 3	
	Settlement check	240	—	—	

SHOCK ABSORBERS

Type: double-action hydraulic	WAY-ASSAUTO	FA-KROSNO
Part number	7591334	7591348
Colour	—	black
Travel (start of damping action)	212 ± 2	216
Maximum extension	337 ± 2	333

00.44

Rear suspension independent with semi-trailing arms, coil springs and hydraulic telescopic shock absorbers.

COIL SPRINGS

Part number	7603855	
Wire diameter	mm	15 ± 0.05
Number of useful coils		4
Direction of spiral		clockwise
Uncompressed spring height	mm	approx. 208
Spring height under load of: 495 ± 17 daN	mm	148
The springs are divided into two grades marked as follows:		
yellow (1) if under a load of: 495 ± 17 daN	height in mm is:	> 148
green (1) if under a load of: 495 ± 17 daN	height in mm is:	≤ 148

(1) The springs must be fitted in matching pairs


SHOCK ABSORBERS

Type: double-action telescopic	WAY-ASSAUTO	FA-KROSNO
Part number	7595878	7591349
Colour	grey	black
Travel (start of damping action)	mm	203 ± 2
Maximum extension	mm	296 ± 2

STARTER MOTOR	Z.E.M. - R 76 a - 0.6 kW - 12 V	
ALTERNATOR	M. Marelli - AA 125 R - 14 V - 45 A Z.E.M. - A115 - 14 V - 43 A	
BATTERY	34 Ah - 12 V - 140 A	
VOLTAGE REGULATOR	Electronic integral	{ FIMM RTT 119 A 15 TR b
IGNITION SYSTEM	contact breaker, with centrifugal and vacuum advance	
IGNITION DISTRIBUTOR	M. Marelli S 314 A ZELMOT 3459 A	
IGNITION COIL	M. Marelli BZ 600 A BIAZET 101	
SPARK PLUGS	M. Marelli F7LCR Champion RN9YC Bosch WR7DC	

STARTER MOTOR - OUTPUT CURVES

RPM kw Nm V



Z.E.M. - R 76 a - 0.6 kW - 12 V

P1V033A01

Electrical system: starting**00.55****STARTER MOTOR**

Type	Z.E.M. - R76a - 0.6 kW - 12 V				
Voltage	V	12			
Rated power	kW	0.6			
Rotation, pinion end	anti-clockwise				
Field coils	4				
Excitation	armature				
Starter drive	overrun clutch				
Operation	electromagnetic				
Armature shaft endfloat	mm	0.15 - 0.45			
Bench test data					
Operating test (*):					
current	A	150			
speed	rpm	capprox. 2100			
voltage	V	9.7			
torque	daNm	0.26			
Engagement test (*):					
current	A	approx. 300			
voltage	V	7.3			
torque	daNm	≥β0.99			
Free running test (*):					
current	A	40 - 50			
voltage	V	11.3			
speed	rpm	> 6000			
Solenoid					
Winding resistance (*)	$\left\{ \begin{array}{l} \text{cut in } \Omega \\ \hline \text{pull in } \Omega \end{array} \right.$	0.33			
		1.27			
Lubrication					
Pinion drive splines and shaft bushes		VS+ SAE 10 W			
Pinion drive sleeve and intermediate plate		TUTELA MR3			

(*) Data measured at an ambient temperature of 20°C.

NOTE When the starter motor is overhauled, the commutator need not be skimmed and undercut

ALTERNATOR

Type		M. Marelli	Z.E.M.
Model		AA 125 R - 14 V - 45 A	A 115 - 14 V - 43 A
Rated voltage	V		14
Maximum current output	A	approx. 47	43
Cut in speed (hot)	rpm	1050	1200
Current delivered to battery at 7000 rpm at operating temp.	A	≥ 45	≥ 43
Stator resistance between the two slip rings (*)	Ω	3 - 3.2	2.7 - 3.3
Direction of rotation (viewed from drive end)			clockwise
Engine/alternator transmission ratio			1 : 2.29
Rectifier diodes			bridge

VOLTAGE REGULATOR

Type		Electronic integral M. Marelli RTT 119 A	Electronic integral 15 TR b
Alternator test speed	rpm		6000
Thermal stabilization current	A		20 - 25
Test current	A		5 - 45
Regulation voltage (*)	V		14 - 14.3


BATTERY

Rated voltage	V	12
Capacity (20-hour discharge rate)	Ah	34


(*) Data measured at an ambient temperature of 20°C

00.55

ALTERNATORS - CURRENT OUTPUT CURVES
(operating temperature, constant voltage of 13.5 V and brushes bedded in)




M. Marelli AA125R - 14V - 45A




Z.E.M. A115 - 14V - 43A

DISTRIBUTORS - ADVANCE CURVES



Graph showing automatic advance of distributor in car



Graph showing vacuum advance of distributor in car

IGNITION DISTRIBUTOR

Type	M. Marelli	ZELMOT
Model	S 314 A	3459 A
Basic ignition setting on idle	10°	
Automatic centrifugal advance	18° ± 2°	
Vacuum advance	15° ± 2°	
Contact breaker points gap mm	0.37 - 0.43	0.47 - 0.55
Cam aperture angle	102° ± 3°	
Cam closure angle	78° ± 3°	
Condenser capacity at 50-1000 Hz µF	0.25 ± 0.025	0.25
Firing order	1 - 2	

IGNITION COIL

Type	M. Marelli	BIAZET
Model	BZ 600 A	101
Primary winding resistance (*) Ω	1.42 - 1.54	1.44 - 1.60
Secondary winding resistance (*) Ω	8100 - 9900	

(*) Data measured at an ambient temperature of 20°C

SPARK PLUGS

Model	M. Marelli 7 LCR Champion RC 9 YC Bosch WR 7 DC
Thread size	M 14 x 1.25
Electrode gap mm	0.6 - 0.7